

AD-A108 103

BOLT BERANEK AND NEWMAN INC CAMBRIDGE MA  
THE TERMINAL INTERFACE MESSAGE PROCESSOR PROGRAM.(U)  
NOV 73

F/G 9/2


DAHC15-69-C-0179

UNCLASSIFIED


TECHNICAL INFORMATION-91

ML

For 3  
A.  
000000







MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A



AD A108108

LEVEL 1





BOLT BERANEK AND NEWMAN, INC.

①  
**LEVEL II**

THE TERMINAL INTERFACE MESSAGE PROCESSOR PROGRAM

August 1973

Update Edition of ~~November 1973~~

APPROVED FOR PUBLIC RELEASE  
DISTRIBUTION UNLIMITED

Accession For	
NTIS GRA&I	<input checked="checked" type="checkbox"/>
DTIC TAB	<input type="checkbox"/>
Unannounced	<input type="checkbox"/>
Justification	
By	
Distribution/	
Availability Codes	
Dist	Avail and/or Special
A	

**DTIC**  
**ELECTE**  
**S** DEC 3 1981 **D**  
**D**

11/73



## Table of Contents

1. Overview of the Terminal IMP Hardware
  2. Software Summary
  3. Performance Summary
  4. Summary of Protocol Design Decisions and Protocol Deviations
    - 4.1 Design Decisions
    - 4.2 Deviations from Protocols
  5. References and TIP Bibliography
  6. Storage Layout
  7. Data Structures
  8. Detailed Software Description
    - 8.1 Outline of Program's Functional Structure
    - 8.2 Detailed Descriptions
    - 8.3 Index to Detailed Descriptions
- Attachments
- I. TIP Site Configuration Macros
  - II. TIP Concordance
  - III. TIP Listing
  - IV. TIP Mag Tape Option Listing



## 1. OVERVIEW OF THE TERMINAL IMP HARDWARE

Understanding the Terminal IMP, software depends on an understanding of the hardware environment in which the software resides. A summary of the Terminal IMP hardware follows.

Up to 63\* terminals, either remote or local, of widely diverse characteristics may be connected to a given TIP and thereby "talk" into the network. It is also possible to connect a Host to a TIP in the usual way a Host is connected to an IMP.

The TIP is built around a Honeywell H-316 computer with 28K of core. It embodies a standard 16-port multiplexed memory channel with priority interrupts and includes a Teletype for debugging and program reloading. Other features of the standard IMP also present are a real-time clock, power-fail and auto-restart mechanisms, and a program-generated interrupt feature. As in the standard IMP, interfaces are provided for connecting to high-speed (50-kilobit, 230.4-kilobit, etc.) modems as well as to Hosts. ←

Aside from the additional 12K of core memory, the primary hardware feature which distinguishes the TIP from a standard IMP is a Multi-Line Controller (MLC) which allows for connection of terminals to the IMP. Any of the MLC lines may go to local terminals or via modems to remote terminals. As shown in Figure 1-1 the MLC consists of two portions, one a piece of central logic which handles the assembly and disassembly of characters and transfers them to and from memory, and the other a set of individual Line Interface Units (all identical except for small number of option jumpers) which synchronize reporting to individual data bits between the central logic and the terminal devices and provide for control and status information to and from the modem or device. Line Interface Units may be physically incorporated one at a time as required.

---

\*There are 64 hardware lines but line 0 is logically reserved by the program for special use.






FIGURE 1-1 BLOCK DIAGRAM OF THE TIP HARDWARE



The MLC connects to the high-speed multiplexed memory channel option of the H-316, and uses three of its channels as well as two priority interrupts and a small number of control instructions.

In order to accommodate a variety of devices, the controller handles a wide range of data rates and character sizes, in both synchronous and asynchronous modes. Data characters of length 5, 6, 7, or 8 bits are allowed by the controller. Since no interpretation of characters is done by the hardware, any character set, such as ASCII or EBCDIC, may be used.

The following is a list of data rates accepted by the controller although all are not yet handled by the software.

SYNCHRONOUS	ASYNCHRONOUS	
	(Nominal Rates)	
Any rate up to and including 19.2 Kb/s	75	1200
	110	1800
	134.5	2400
	150	4800
	300	9600
	600	19200
	All above in bits/second	
	} output only	

The data format required of all devices is bit serial; each character indicates its own beginning by means of a start bit preceding the data and includes one or more stop bits at the end of the character.

Given these characteristics, then, the controller will connect to the great majority of normal terminal devices such as Teletypes, alphanumeric CRT units, and modems, and also (with suitable remote interface units) to many peripheral devices such as card readers, line printers, and graphics terminals. Either full or half duplex devices can be accommodated. The standard TIP program cannot deal with a magnetic tape unit through the MLC. However, as a special



option, and with the use of additional core memory, standard Honeywell tape drives can be connected to the TIP as normal peripherals.

The individual terminal line levels are consistent with EIA RS-232C convention. Data rates and character length are individually set for each line *by the program*. For incoming asynchronous lines, the program includes the capability for detecting character length and line data rate as discussed below.

Logically, the controller consists of 64 input ports and 64 output ports. Each input/output pair is brought out to a single connector which is normally connected to a single device. However, by using a special "Y" cable, the ports may go to completely separate devices of entirely different properties. Thus, *input* port 16 may connect to a slow, asynchronous, 5-bit character keyboard while *output* port 16 connects to a high speed, synchronous display of some sort. In order to achieve this flexibility, the MLC stores information about each input and each output port and the program sets up this information for each half of each port in turn as it turns the ports "ON."

Several aspects of the MLC design are noteworthy. The central logic treats each of the 64 ports in succession, each port getting 800 ns of attention per cycle. The port then waits the remainder of the cycle (51.2  $\mu$ s) for its next turn. For both input and output, two full characters are buffered in the central logic, the one currently being assembled or disassembled and one further character to allow for delays in memory accessing.

During input, characters from the various lines stream into a tumble table in memory on a first come, first served basis. Periodically a clock interrupt causes the program to switch tables and look for input.



Output characters are fed to all lines from a single output table. Ordering the characters in this table in such a way as to keep a set of lines of widely diverse speeds solidly occupied is a difficult task. To assist the program in this, a novel mechanism has been built into the MLC hardware whereby each line, as it uses up a character from the output table, enters a request consisting of its line number into a "request" table in memory. This table is periodically inspected by the program and the requests are used in building the next output table with the characters in proper line sequence.

The design of the terminal interface portion of the MLC is modular. Each Line Interface Unit (LIU) contains all the logic required for full duplex, bit serial communication and consists of a basic bi-directional data section and a control and status section. The data section contains transmit and receive portions each with clock and data lines. For asynchronous devices the clock line is ignored and timing is provided by the MLC itself. (For received asynchronous characters, timing is triggered by the leading edge of the start bit of each character.)

The control and status monitor functions are provided for modems as required by the RS-232C specification. Four outputs are available for control functions and six inputs are available to monitor status. The outputs are under program control and are available for non-standard functions if the data terminal is not a modem. For example, these lines could be used to operate a local line printer. RS-232C connectors are mounted directly on the LIU cards. To allow for variations in terminal and modem pin assignments, the signals are brought to connector pins via jumpers on the card.



## 2. SOFTWARE SUMMARY

Because the terminals connected to a TIP communicate with Hosts at remote sites, the TIP, in addition to performing the IMP function, also acts as intermediary between the terminal and the distant Host. This means that network standards for format and protocol must be implemented in the TIP. One can thus think of the TIP software as containing both a very simpleminded mini-Host and a regular IMP program.

Figure 2-1 gives a simplified diagrammatic view of the program. The lower block marked "IMP" represents the usual IMP program. The two lines into and out of that block are logically equivalent to input and output from a Host. The code conversion blocks are in fact surprisingly complex and include all of the material for dealing with diverse (and perverse) types of terminals.

As the user types on the keyboard, characters go, via input code conversion, to the input block. Information for remote sites is formed into regular network messages and passes through the OR switch to the IMP program for transmittal. Command characters are fed off to the side to the command block where commands are decoded. The commands are then "performed" in that they either set some appropriate parameter or a flag which calls for later action. An example of this is the LOGIN command. Such a command in fact triggers a complex network protocol procedure, the various steps of which are performed by the PROTOCOL block working in conjunction with the remote Host through the IMPs. As part of this process an appropriate special message will be sent to the terminal via the Special Messages block indicating the status (success, failure, etc.) of the procedure.






FIGURE 2-1 BLOCK DIAGRAM OF TIP PROGRAM



Once connection to a remote Host is established, regular messages flow directly through the Input block and on through the IMP program. Returning responses come in through the IMP, into the OUTPUT program where they are fed through the OUTPUT Code Conversion block to the terminal itself.



### 3. PERFORMANCE SUMMARY

The program can handle approximately 100 kilobits of one-way terminal traffic provided the message size is sufficiently large that per-message processing is amortized over many characters. Overhead per message is such that if individual characters are sent one at a time there is a loss of somewhere between a factor of ten and twenty in bandwidth. A different way to look at program performance is to observe that the per-character processing time is about 75  $\mu$ s.

These figures ignore the fact that the machine must devote some of its bandwidth to acting as an IMP, both for terminal traffic and for regular network traffic. About 5% of the machine is lost to acting as an IMP, even in the absence of traffic. If there is network traffic, more of the machine bandwidth is used up. Five hundred kilobits of two-way phone line and Host traffic saturates the machine without any terminal traffic\*.

In addition to bandwidth which goes into the IMP part of the job, another 10 percent of the (total) machine is taken up simply in fielding clock interrupts from the Multi-Line Controller. This again is bandwidth used in idling even with no actual terminal traffic.

The following formula summarizes, approximately, the bandwidth capabilities:

$$P + H + 11T \leq 850$$

\*The number 500 kilobits is for full size (8000 bit) messages. Shorter messages use up more capability per bit and thus reduce the overall bandwidth capability.



where:

- P = total phone line traffic (in kilobits/sec) wherein, for example, a full duplex 50 Kb phone line counts as 100;
- H = total Host traffic (in kilobits/sec) wherein the usual full duplex Host interface, with its usual 10  $\mu$ s/bit setting, counts as 200; and
- T = total terminal traffic (in kilobits/sec) wherein an ASCII terminal such as a (110-baud) full-duplex Teletype (ANSI-33) counts as twice its baud rate (i.e., 0.220 Kb).

This means that it takes eleven times as much program time to service every terminal character as it does to service a character's worth of phone line or Host message.

A further factor that influences terminal traffic handling capability has to do with the terminals themselves. Certain types of terminals require more attention from the program than others, independent of their speed but based rather on their complexity. In particular, for example, while an IBM 2741 nominally runs at 134.5 bits per second, the complexity is such that it uses nearly three times the program bandwidth that would be used in servicing a half-duplex ASCII terminal of equivalent speed. Allowances for such variations must be made in computing the machine's ability to service a particular configuration. It must be borne in mind that all of these performance figures are approximations and that the actual rules are extremely complex.



#### 4. SUMMARY OF PROTOCOL DESIGN DECISIONS AND PROTOCOL DEVIATIONS

This section discusses the Terminal IMP's implementation of its Network Control Program (NCP) for the Host/Host Protocol [1], Initial Connection Protocol (ICP) [2], and TELNET [3]. Included are descriptions of the design decisions made where such decisions are permitted by the protocols, and of instances of non-compliance with the protocols.

Most of the choices made during protocol implementation on the Terminal IMP were influenced strongly by storage limitations. The Terminal IMP has no bulk storage for buffering, and has only 12 kilowords of 16-bit words available for both device I/O buffers and program. The program must drive up to 63 terminals which will generally include a variety of terminal types with differing code sets and communication protocols (e.g., the IBM 2741 terminals). In addition, the Terminal IMP must include a rudimentary language processor which allows a terminal user to specify parameters affecting his network connections. Since the Terminal IMP exists only to provide access to the network for 63 terminals, it must be prepared to maintain 126 (simplex) network connections at any time; thus each word stored in the NCP tables on a per-connection basis consumes a significant portion of the Terminal IMP memory.

It should be remembered that the Terminal IMP is designed to provide access to the network for its users, not to provide service to the rest of the network. Thus the Terminal IMP does not contain programs to perform the "server" portion of the ICP; in fact, it does not have a "logger" socket.



## 4.1 Design Decisions

4.1.1. The Terminal IMP ignores incoming ERR commands and does not output ERR commands.

4.1.2. The Terminal IMP assumes that incoming messages have the format and contents demanded by the relevant protocols. For example, the byte size of incoming TELNET messages is assumed to be 8. The major checks which the Terminal IMP does make are:

- 1) If an incoming control message has a byte count greater than 120 then it is discarded.
- 2) If a control command opcode greater than 13 is found during the processing of a control message then the remainder of the control message is discarded.
- 3) If an incoming data message has a byte count indicating that the bit allocation for the connection is exceeded (based on the assumed byte size) then the message is discarded.

4.1.3 If one control message contains several RST commands only one RRP is transmitted. If several control messages, each containing RST commands, arrive "close together" only one RRP is returned. [The actual implementation is to set a bit each time a RST is found (in "foreground") and to reset the bit when a RRP is sent (in "background")].

4.1.4 Socket numbers and the link for receive connections are pre-assigned based on the hardware "physical address" (in the terminal multiplexing device) of the terminal. The high order 16 bits of the socket number give the device number (in the range 0-63) and the low order 16 bits are normally 2 or 3 depending on the socket's gender (zero is also used during ICP); the TIP requires servers to send data to it on link "device number" +2 [range 2-65].



4.1.5 During ICP, with the Terminal IMP as the user site, the Terminal IMP follows the "Listen" option rather than the "Init" option (as described at the top of page 3 of [2]). In other words, the Terminal IMP does not issue the RFCs involving sockets U+2 and U+3 except in response to incoming RFCs involving those sockets.

4.1.6 The TIP clears out its connection tables as it sends an RST, and then immediately continues operations with the affected Host. RRP's are ignored.



## 4.2 Deviations from Protocols

4.2.1 The Terminal IMP does not guarantee to issue CLS commands in response to "unsolicited" RFCs. There are currently several ways to "solicit" an RFC, as follows:

- 1) A terminal user can tell the Terminal IMP to perform the ICP to the TELNET Logger at some foreign Host. This action "solicits" the RFCs defined by the ICP.
- 2) A terminal user can send an RFC to any particular Host and socket he chooses. This "solicits" a matching RFC.
- 3) A terminal user can set his own receive socket "wild." This action "solicits" an STR from anyone to his socket. Similarly, the user can set his send socket "wild" to "solicit" an RTS.

If the terminal IMP receives a "solicited" RFC, it handles it in accordance with the protocol. For unsolicited RFCs, the Terminal IMP maintains a two-entry reply queue. When an unsolicited RFC is received, permanent information is placed on the queue if there is room; if not, the RFC is ignored. In the "background", the queue is emptied by constructing the appropriate CLSs.



4.2.2. After issuing a CLS for a connection, the Terminal IMP will not wait forever for a matching CLS. There are two cases:

- 1) The Terminal IMP has sent an RFC, grown tired of waiting for a matching RFC, and therefore issued a CLS.
- 2) The Terminal IMP has sent a CLS for an established connection (matching RFCs exchanged).

In either of these cases the Terminal IMP will wait for a matching CLS for a "reasonable" time (probably 30 seconds to one minute) and will then "forget" the connection. After the connection is forgotten, the Terminal IMP will consider both sockets involved to be free for other use.

Because of program size and table size restrictions, the Terminal IMP assigns socket numbers to a terminal as a direct function of the physical address of the terminal. Thus (given this socket assignment scheme) the failure of some foreign Host to answer a CLS could permanently "hang" a terminal. It might be argued that the Terminal IMP could issue a RST to the offending Host, but this would also break the connections of other terminal users who might be performing useful work with that Host.



4.2.3 The Terminal IMP ignores all RET commands. The Terminal IMP cannot buffer very much input from the network to a given terminal because of core size limitations. Accordingly, the Terminal IMP allocates only one message and a small number of bits on each connection for which the Terminal IMP is the receiver. The Terminal IMP attempts to keep the usable bandwidth as high as possible by sending a new allocation, which brings the total allocation up to the maximum amount, each time that:

- 1) one of the two buffers assigned to the terminal is empty, and
- 2) the allocations are below the maxima.

Thus, if a spontaneous RET were received, the reasonable thing for the Terminal IMP to do would be to immediately issue a new ALL. However, if a foreign Host had some reason for issuing a first spontaneous RET, it would probably issue a second RET as soon as it received the ALL. This would be likely to lead to an infinite (and very rapid) RET-ALL loop between the two machines, chewing up a considerable portion of the Terminal IMP's bandwidth. Since the Terminal IMP can't "afford" to communicate with such a Host, it ignores all RETs.



4.2.4. The Terminal IMP ignores all GVB commands. Implementation of GVB appears to require an unreasonable number of instructions and, at the moment at least, no Host appears to use the GVB command. If we were to implement GVB we would always RET all of both allocations and this doesn't seem very useful.



4.2.5. The Terminal IMP does not handle a total bit-allocation greater than  $65,534 (2^{16}-2)$  correctly. If the bit-allocation is ever raised above 65,534 the Terminal IMP will treat the allocation as infinite. This treatment allows the Terminal IMP to store the bit allocation for each connection in a single word, and to avoid double precision addition and subtraction. Our reasons for this decision are:

- 1) We save more than 100 words of memory which would be required for allocation tables and for double precision addition/subtraction routines.
- 2) Our experience indicates that very few Hosts (probably one at most) ever raise their total bit allocation above 65,534 bits.
- 3) We expect that any Host that ever raises its bit allocation above 65,534 would probably be willing to issue an infinite bit allocation if one were provided by the protocol. Once the bit allocation is greater than about 16,000, the message allocation (which the Terminal IMP handles correctly) is a more powerful method of controlling network loading of a Host system than bit allocation.



4.2.6. The Terminal IMP ignores the "32-bit number" in the ICP. When the Terminal IMP (the "user site") initiates the Initial Connection Protocol the actual procedure is to send the required RTS to the logger socket of the user-specified foreign Host and simultaneously to set the terminal user's send and receive sockets in a state where each will accept any RFC from the specified Host. The 32-bit socket number transmitted over the logger connection is ignored, and the first RTS and STR addressing the user's sockets will be accepted (and answered with matching RFCs).

The ICP allows the foreign Host to transmit the RFCs involving Terminal IMP sockets "U+2" and "U+3" at any time after receipt of the RFC to the (foreign Host's) logger socket. In particular, the RFCs may arrive at the Terminal IMP before the 32-bit number. In the case of a "normal" foreign Host, the first incoming RFCs for sockets U+2 and U+3 will come from the sockets indicated by the 32-bit number, so it doesn't matter if the number is ignored. In the case of a pathologic foreign Host, a potentially infinite number of "wrong" RFCs involving U+2 and U+3 may arrive at the Terminal IMP before the 32-bit number is sent. The Terminal IMP would be required to store this stream of RFCs pending arrival of the 32-bit number, then issue CLS commands for all "wrong" RFCs. However, the Terminal IMP does not have infinite storage available for this purpose (it is also doubtful that a terminal user really wants to converse with a pathologic foreign Host) so the Terminal IMP assumes that the foreign Host is "normal" and ignores the 32-bit number.



4.2.7 The terminal IMP does not guarantee correct response to ECO commands. ECOs are handled in exactly the same fashion as RSTs [a bit which is set is foreground and cleared in background], but for ECO, this approach constitutes a violation.

The reasons for this method of implementation is that to guarantee correct response to ECO in all cases requires an infinite amount of storage. For example, suppose Host A sends control messages, each containing an ECO command, to Host B at the rate of one per second, but that Host A accepts messages from the network as slowly as possible (one every 39 seconds, say). Then Host B has only three choices which do not violate protocol:

- 1) Declare itself dead to the network (i.e., turn off its Ready line), thereby denying all its users use of the network.
- 2) Refuse to accept messages from the network faster than the slowest possible foreign Host (i.e., about one every 39 seconds). If Host B is a Terminal IMP, this is almost certainly slow enough to soon reach a steady state of no users.
- 3) Implement "infinite" storage for buffering messages.

Since it is clear that none of the "legal" solutions are possible, we have decided to provide buffering for one ERP to each possible Host, which should be adequate well over 99% of the time.



4.2.8 INSS and DMs are counted only mod4 with the counter nominally at 0 and INSS decrementing it and DMs incrementing it. When the counter is at 2 or 3, output is suppressed. Thus, if there are a large number of TELNET SYNCHs in progress (to a single port) simultaneously, some of the SYNCHs will not have been handled correctly.

The reason for this method of implementation is that protocol requires a potentially infinite counter to keep track of INSS that have not yet been matched. Further, since this method will always fall back in synch when the matching DMs eventually do come in, the only effect of this is occasionally not suppressing output when it should have been.



## 5. References and TIP Bibliography

- [1] NIC 8246, Host/Host Protocol for the ARPA Network, January 1972.
- [2] NIC 7101, Official Initial Connection Protocol, June 1971.
- [3] NIC 9348, Ad Hoc Telnet Protocol, April 1972.
- [4] The BBN TIP Hardware Manual, BBN Report No. 2184.
- [5] Specifications for the Interconnection of Terminals and the Terminal IMP, BBN Report No. 2277.
- [6] Terminal Interface Message Processor User's Guide, BBN Report No. 2183.
- [7] S.M. Ornstein et al, The Terminal IMP for the ARPA Computer Network, Proc. AQIPS 1972 SJCC., pp. 243-254.
- [8] N.W. Mimno et al, Terminal Access to the ARPA Network: Experience and Improvements, Proc. Seventh Annual IEEE Computer Society International Conference, pp. 39-43.
- [9] R.E. Kahn, Terminal Access to the ARPA Computer Network, Computer Networks, Courant Computer Symposium 3, Courant Institute, New York.
- [10] TIP User's Group Notes, Available from the Network Information Center, Stanford Research Institute, Menlo Park, California 94025.



## 6. Storage Layout

There follow three figures which illustrate the layout of core storage for the TIP software system.

The numbers down the left side and across the top of the tables are given in octal and represent memory addresses.






FIGURE 6-1(A) STORAGE LAYOUT






FIGURE 6 - 1(B) STORAGE LAYOUT






FIGURE 6-1(C) STORAGE LAYOUT



## 7. Data Structures

Following are the formats of the individual entries of every important table or data structure in the TIP software system. These charts are useful in studying the TIP system listing and the detailed software descriptions.

The tables are invariably sixty-four entries long or, as is occasionally necessary, made up of two or more contiguous tables sixty-four entries long. Often several tables only a few bits wide are packed in one word.



DEVICE-----

FORWARD  
CHILDS

DEVICE-----

ECN-02  
02115

DEVICE-----

```

|---|---|---|---|---|---|---|---|---|---|
|---|---|---|X|---|---|---|---|---|---|
|---|---|---|---|---|---|---|---|---|---|
\-----/      | ! ! ! ! !
                  | ! ! ! ! \--MDRRI: DON'T RESET DRUM
                  | ! ! ! !   INPUT
                  | ! ! ! ! \--MDRRM: DON'T RESET DRUM O
                  | ! ! ! !   UTPUT
                  | ! ! ! ! \--MDECH1: VIRTUAL FULL DUPLEX
                  | ! ! ! ! \--MDECH2: PHYSICAL HALF DUPLEX
                  | ! ! ! ! \--MDBIN0: BINARY OUTPUT MODE
                  | ! ! ! ! \--FINAL CHAN TO FCHO WITH

```



```


JUMPIN----! ! DISPATCH ADDRESS FOR NEXT INPUT
-----
NEXTIN----! ! INPUT CHAR PTR
-----
CNTN-----! ! CTR FOR ROOM LEFT IN BUFFER
-----
HIGHBUF----! ! PTRS TO ENDS OF INPUT BUFFERS
-----
LASTTC----! ! # OF CHARS SENT IN LAST DATA MESSAGE
-----

```

```
DIJMP-----! | DISPATCH TO FIND NEXT OUTPUT CHAR  
OUTNXT-----! | PTR TO NEXT CHAR TO GO  
BYTCNT-----! | CTR OF CHARS LEFT IN THIS OUTPUT  
OUCOPY-----! /--|  
| |  
| |  
| |  
|--| |  
| |  
| |  
| \-----/  
| |--PTRS TO ENDS OF OUTPUT BUFFERS  
|--TB; WHICH DOUBLE BUFFER IS IN USE
```



HOSTAB  
CVTH  
CVTRP  
MAT1  
MAT2  
MAT3  
MAT4





```

| | . - . | - . - | - . - . | - . - . |  

| X ! ! ! ! !  

| - | - . - . | - . - | - . - . | - . - . |  

| | | | | \-----/  

| | | | | \--CVTB & CVTSP  

| | | | \--SNDRRP; SEND AN RRP  

| | | \--SNDERP; SEND AN ERP  

| | \--SNORST; SEND A RESET  

| \--LNKØBL; CTL LINK BLOCKED  

\--LNKØTM; TIMING OUT BLOCKED CONTROL LINK
```

[illegible]

```

|-.-.-.-.-|
| |X| | | | |
|-.-.-.-.-|
\-/ | \--/ | | \-----)
| | | | | \--ESCCHR; ESCAPE CHAR
| | | | | \--MDPERM; ESCAPE CHAR IS PERMANENT
| | | | | \--ONMOR; EXTRA OI ADDED ALREADY
| | | | | \--MEXTRA; # OF EXTRA OI'S REQUIRED FOR FULL SP
| | | | | EED
| | | | | \--MOHANGI DATA SET IS HANGING UP
|--INSCNT; INS & DM COUNTER

```



```

DEVICE-----! !-.-.-.-.-!-.-.-.-.-!-.-.-.-.-!
                !-.-.-.-.-!-.-.-.-.-!-.-.-.-.-!
                \-----/ \----/ \---/
                  |         |         |
                  |         |         | \--SND CONNECTION STATE
                  |         |         | \--"THE" LIU CONTROL BIT
                  |         |         | \--LIU CONTROL BITS -- HELD ON
                  |         |         | \--LIU CROSSPATCH
                  |         |         | \--CHANC; CHARS/MSG

```

```

DEVICE----! :!-.-.-!-.-.-!-.-.-!-.-.-!-.-.-!
             !!-.-.-!-.-.-!-.-.-!-.-.-!-.-.-!
             !\-----/\-----/\-----/
               !           !           !           \--RCV CONNECTION STATE
               !           !           !           \--MWDEV: # OF DEV OWNED BY THIS ONE
               !           !           !           \--MWCAPT: DEVICE OWNING THIS ONE
               !           !           !           \--MDIVRT: THIS DEVICE DIVERTING

```

```
MODE-----! /-! !  
! !  
! !  
MBITS-----! /+---! !  
! !  
! !  
! !-!-.--!-.-.-!-.-.-!-.-.-!  
! \--! ! !X! ! !XXXXXXXXXXXXXXXXXXXXXX!  
! !-!-.--!-.-.-!-.-.-!-.-.-!  
! ! ! \-/!  
! ! ! \--TIMEC3,TIMEC1: TIMEOUT CLOSE ON XMT CONNE  
! ! ! CTION  
! ! ! \--MDSINT; SEND AN MP INTERRUPT  
! ! ! \--MDSALL: SEND AN ALLOCATE  
! ! ! \--MIGOTO: OUTPUT WAITING  
! !  
! !-!-.--!-.-.-!-.-.-!-.-.-!  
! \----! ! ! !XXXXXXXXXXXXXXXXXXXXXX!  
! !-!-.--!-.-.-!-.-.-!-.-.-!  
! ! ! \-/ \-/!  
! ! ! \--TIMEC3,TIMEC1 FOR RCV CONNECTION  
! ! ! \--MDLSTO: TIMEOUT BLOCKED DATA LINK  
! ! ! \--MDNEWS: LOOKING FOR AN RSEXEC SERVER  
! ! ! \--MDLNKR: DATA LINK BLOCKED
```



SUCKS!----! ! ! SEND SOCKET, WORD 1

SOCKS2----! !                   ! SEND SOCKET, WORD 2

HOSTS  
LINK

FLSTR  
COMMAND

ALLOC  
ALLGCM  
ALLOCO

```

ALLOCN=---!      !      MSG ALLOC LEFT (-1=INF)

```

7-7



ASCII-----!

[illegible]

DEVICE-----!

```

!-.-.-.-.-!-.-.-.-.-!-.-.-.-.-!-.-.-.-.-!  

!XXXXXXXXXX!!  

!-.-.-.-.-!-.-.-.-.-!-.-.-.-.-!  

\-----/  

|      |      |  

|      |      | \--MGOTR; JUST SENT A CR  

|      |      | \--MGOTCR; ODEC CR CTRL  

|      |      | \--MDNCOM; COMMANDS COMING FROM NET  

|      |      | \--LUC OF PRINHEAD

```



## 8. Detailed Software Description

Section 8.1 gives an overview of the various functional modules in the TIP program and the main routines which perform these functions. Section 8.2 contains the bulk of the material in Section 8, the detailed software descriptions themselves. Section 8.3 is an index of the "labels" used in Section 8.2.




## 8.1 Outline of Program's Functional Structure


The figure gives a broad outline of the data paths in the IMP system software. Data paths are marked with directed arcs. A few important paths (marked with dashed arcs) which control the flow over the paths are also shown.

The figure after next indicates some of the routines along the data paths and serves as an overview of the detailed descriptions of the next section. The following two figures should be studied together.











## 8.2 Detailed Descriptions

The detailed descriptions in the rest of this section are a mixture of descriptive prose and diagrams. Very few of the diagrams are precise flow charts of the actual code; instead, the diagrams vary from functional descriptions of what the routine under consideration does, to state diagrams for the conceptual finite state machines that the routine implements, to logic diagrams for the routine. Study of the remainder of this section assumes concurrent study of the program listing and the formats of the program data structures. In the following diagrams, wherever reasonable, the diagram labels are keyed to the program labels found in the listing for convenient cross-referencing.

Many of the diagrams are given in an ALGOL-like notation where labels appear in the left column and "goto"s and "if"s are used to indicate branches in program flow. This notation is used instead of a more conventional two-dimensional notation to facilitate computer maintenance of the diagrams. In the absence of "goto"s, "call"s, etc. program flow is assumed to go down the page and from one page to the next.

The program descriptions in the rest of this section are generally organized by program priority level (initialization, MLC clock interrupt, background, MLC output interrupt, and mag tape option) as shown in the following hierarchical outline. Again, this organization is to facilitate cross-referencing the descriptions with the listing.



- 8.2.1 Initialization
- 8.2.2 Clock Level
  - 8.2.2.1 MLC Input
    - 8.2.2.1.1 Packing data into input buffers
    - 8.2.2.1.2 Echo initiation
    - 8.2.2.1.3 User command processing
      - 8.2.2.1.3.1 Command interpretation
      - 8.2.2.1.3.2 Command execution
    - 8.2.2.1.4 Rate initialization for "hunting" devices
    - 8.2.2.1.5 Input conversion
      - 8.2.2.1.5.1 EBCDIC to ASCII
  - 8.2.2.2 MLC Output (Outin's)
    - 8.2.2.2.1 2741 line control
    - 8.2.2.2.2 Telnet protocol
      - 8.2.2.2.2.1 FIXECH
    - 8.2.2.2.3 Echoes
    - 8.2.2.2.4 Messages to devices
    - 8.2.2.2.5 Output Conversion
      - 8.2.2.2.5.1 ASCII to EBCDIC Conversion Logic
      - 8.2.2.2.5.2 Slow carriage return
      - 8.2.2.2.5.3 Even Parity
      - 8.2.2.2.5.4 Line Printers
        - 8.2.2.2.5.4.1 MEMORX
        - 8.2.2.2.5.4.2 ODEC
  - 8.2.2.3 Background timer
- 8.2.3 Background
  - 8.2.3.1 Connection and Host functions
    - 8.2.3.1.1 Device related functions
      - 8.2.3.1.1.1 Transfer of data to the IMP
      - 8.2.3.1.1.2 Allocates
      - 8.2.3.1.1.2 News



- 8.2.3.1.2 Host related functions
  - 8.2.3.1.2.1 Send INS's
  - 8.2.3.1.2.2 Send ERP's, RST's, and RRP's
  - 8.2.3.1.2.3 Send CLS's for unsolicited RFC's and CLS's
- 8.2.3.2 Connection Control
- 8.2.3.3 Initial Connection Protocol
- 8.2.3.4 Send data to IMP
  - 8.2.3.4.1 Link Ø
  - 8.2.3.4.2 Not link Ø
- 8.2.3.5 Accept data from IMP
  - 8.2.3.5.1 Irregular Messages
  - 8.2.3.5.2 Regular Messages
    - 8.2.3.5.2.1 Link Ø messages
      - 8.2.3.5.2.1.1 Handling RFC's and CLS's
      - 8.2.3.5.2.1.2 Handling ECO's and RST's
      - 8.2.3.5.2.1.3 Handling Allocates
      - 8.2.3.5.2.1.4 Counting INS's
    - 8.2.3.5.2.2 Messages not on link Ø
      - 8.2.3.5.2.2.1 OUNEW
- 8.2.3.6 Modem and LIU control
- 8.2.4 MLC Output interrupt
- 8.2.5 Magnetic tape option
- 8.3 Index to Detailed Descriptions



### 8.2.1 Initialization

Initialization comes in two classes: complete TIP initialization (done by the routine GOGGLE), and device initialization (done by the routine RESET).

GOGGLE is called at the top of the TIP background loop if the TIP (re)initialization flag (TIPFLG) is set. RESET is called by GOGGLE as part of complete TIP initialization, and by MODEMS, HUNT, and RC for device initialization, the latter being the RESET command.



GOGGLE    shut off TIP interrupts

          reset the MLC

          set up Page 0 literals

          for all Hosts, mark to send RSTs

          initialize device stuff including  
          call to RESET

          zero various flags

          initialize MLC output buffer pointers

          initialize various co-routines

          initialize various timers

          set up correct priority  
          interrupt mask for clock level

          initialize MLC IN and OUTIN buffer pointers

          initialize Mag tape option if it exists

          set up interrupt entrances

          return from GOGGLE



The subroutine RESET, following, initializes a device. It is called by various routines, including: GOGGLE (initialization), MODEMC, HUNT, and the user RESET command. RESET makes a distinction between hunting and non-hunting devices; the latter keep certain parameters set even through a reset. On entry, the device to be reset is indicated by the index register.

RESET performs the following functions for all devices, hunting or not:

- initializes internal status bits (allocates, blocked links, etc.);
- sets the escape character to the default unless marked as permanent;
- initializes connections (allocates and links) by calling SHUTDN if not open, or if an open connection exists, initiates a close;
- aborts any login, open, or news request in progress;
- initializes buffer pointers and count;
- releases any devices captured by this one, and uncaptures this device if captured;
- sets up the appropriate dispatch for input characters.

In addition, RESET performs the following functions for hunting devices only:

- changes the device rate to the nominal hunting rate;
- resets the "connection" parameters to their default conditions of not wild, non-binary output, transmit on every character (and not specifically on an EOM or EOL), local echo mode, and add a linefeed after a carriage return.



RESET      if device is invalid, return from  
            RESET

            initialize status bits

            if escape character is permanent,  
            reset escape character to @

RESET5     initialize (close) connections

            initialize buffer pointers  
            and count

            uncapture the device and any  
            other devices it may have captured

            if device is hunting device,  
            goto RESETa

            set up correct input dispatch

            return from RESET

RESETa     set the rate to hunting

            initialize the connection  
            parameters

            set input dispatch to HUNT

            return from RESET



### 8.2.2 MLC CLOCK Level

The MLC clock level routine, CLOCK, is mostly a straight series of calls to other clock level routines and inline code.

CLOCK	save registers and keys and mask
	set up new mask
	if 40 ticks of PEND clock have not gone by, goto CLOCK4
	reset PEND clock
	reset LOG clock
	reset PEND flag
	mark that TIP is ready (for NCC)
	increment data set control timer
CLOCK4	do MLC input
DOTN2	pack data into device input buffers



OOPS

call CLKOI

call BTIME

if output not busy, call TOUT  
to restart it

restore registers, mask, and keys

return from CLOCK



#### 8.2.2.1 MLC Input

The inline code following CLOCK4 in CLOCK performs MLC input as shown.



swap buffers

set up MLC input  
buffer pointers to  
new input buffer

set up pointer  
to input buffer to  
be emptied

goto DOTN2



#### 8.2.2.1.1 Packing Data into INPUT Buffers

The input routine starting at DOTN is called on an interrupt basis. Characters input to the MLC are stored in a (double-buffered) tumble table where each entry consists of the character and an index to the originating device. Each clock time of 3.3 msec, one of these tumble tables is processed by the input routines, character-by-character. The disposition of input is indicated by the JUMPIN table which contains a dispatch (jump instruction) for each device; specific dispatches are detailed in the following flow charts. Generally they distinguish from each other: data, commands, echoing or not echoing, ASCII input and input requiring code conversion, input considered 8-bit binary, and the special case of the initial character(s) from a hunting device. Clearly, the dispatch changes as a user sets up and then executes a dialogue with a Host system.



DOTN        increment to get next entry  
             from tumble table

DOTN2       pick up a character and device  
             number from tumble table and  
             save them

             if character is a  
             break, goto BREAK

             dispatch via table entry for this  
             device to one of CONECO, CONVT, CONEEE,  
             CONESC, IBMEEE, IBMESC, IBMECO, IBMCON,  
             BINECO, BINCON, or HUNT



BREAK      if device is hunting, goto HUNT  
  
            if device is a 2741, goto IBBRAK  
  
            convert character to TELNET break character  
  
            goto NOPE



BINECO     call ECHO  
            to echo character

BINCON     goto NOPE

IBMEEE  
IBMESC     call IBMIN to convert  
            character and do protocol

            goto ESC

IBMECO  
IBMCON     call IBMIN to convert character  
            and do protocol

            goto REG



REG        if device has suppressed intercepting  
             commands, goto REGa

             if character is the device's escape  
             character, goto ESCAPE

REGa       if character is a LF, goto FEED

             if character is an EOM, goto EOM

NOPE        if there is no space in buffer,  
             goto ECHBEL

             store the character in buffer

             if there is no space left, call  
             SENDIT to mark it to be sent to net

ADDLF       if not in add LF mode,  
             goto DOTN

             if character is a CR, change  
             character in tumble table to a LF

             goto DOTN2



ECHBEL      don't echo the character, but  
             send out a BEL code (upshift  
             for IBMs) to show character was discarded

             goto DOTN

FEED          if device not set to  
             transmit on LF, goto NOPE

             goto EOMa

EOM           if device not set to transmit  
             on EDM, goto NOPE

EOMa          set up counter to make buffer look full

             goto NOPE



CONEEE	call ECHO to echo character
CONESC	mask character to seven bits
ESC	if character is a CR, goto ADDLF
	call ESC1 to interpret command character
	if return 1 from ESC1, goto DOTN
ESC2	set up table dispatch to expect data
	if character is an esc which is to be data, goto NOPE
	terminate command by sending device CR-LF
	goto DOTN



#### 8.2.2.1.2 Echo initiation

The ECHO subroutine performs local echoing for the TIP. It has table storage space allowing two echo characters to be saved for each device, tables ECHWD1 and ECHWD2. Echo characters take priority over regular data for output.



ECHO       if OI dispatch is ECHL,  
            goto DOTN

            if OI dispatch is ECHR, reset  
            OI dispatch to ECHL

            if OI dispatch is neither ECHL or ECHR,  
            set OI dispatch to ECHR

            copy ECHWD2 to ECHWD1

            put new character in ECHWD2

            restart output to the terminal  
            by calling OUNEW

            return from ECHO



### 8.2.2.1.3 User command processing

#### 8.2.2.1.3.1 Command interpretation

The subroutine ESC1 interprets local TIP commands. Each time through, ESC1 interprets one character which must be in the AC when it is called. The command status of each device is saved in a table called COMAND and converted to the temporary parameter COM when ESC1 is called. Only the first character of a word is significant; the command @ABORT LOGIN, for example, is equivalent to @A L. Extra spaces and the rest of each word are ignored by ESC1. By default, a command affects the device from which it was given. If, however, a command is preceded by a number (as in @2 A L, a command will affect the device so designated (in this case device 2). In this case the affected device is captured by the commanding device (which may be itself) and cannot be commanded by any other device until it is "given back" with a GIVE BACK or RESET command. In general, there are two kinds of commands, those with and those without parameters. Once the command is accepted and interpreted, ESC1 dispatches to specific code for each command. Parameters, if any, follow the command itself (e.g., @L 69) and are interpreted by this specific command code. Descriptions of these specific commands appear in the next section.



ESC1       initialize SKIPS, LFFLG; save character

          if mag tape command, goto MC

          look for a special character

          if character is not a space,  
          goto ESC1a

          ignore character; reset flag

          return 1 from ESC1 to wait for next  
          character



ESCl a     if character is a LF, goto RETURN

          if character is TELNET control, return 1  
          from ESC1 to wait for next character

          if character is rubout, goto EXIT

          if character is lower case, convert  
          it to upper case



Q2           look at status now

          if a space is needed, return 1 from ESC1  
          to wait for next character

          if a command has already been matched,  
          goto PAR

          if we are interpreting a command,  
          goto SYNTAX

          if still looking for number, goto Q3

          if character is an esc, goto EXIT

          undivert output

          goto Q3

EXIT       clean up

          return 2 from ESC1 to indicate done



RETURN    if have nothing yet, goto EXIT

          if haven't got a dispatch yet,  
          goto RETURNa

          set up dispatch address

          goto DISP

RETURNa    reset space flag, set LF flag

          goto SSYN1



PAR        set up parameter  
          dispatch

          goto DISPC

Q3         if character is a number, goto  
          Q3a

SSYN1      correct status

          goto SYNTAX

Q3a        accumulate a diverting device

          set status to looking  
          for number

          return 1 from ESC1 to wait  
          for next character



SYNTAX	interpret command syntax
Q6	pick up the next character to match
	if this one is not to be skipped, goto Q6a
	adjust SKIPs flag
	goto Q6
Q6a	if not at end of tree, goto Q8
	if a parameter is needed, goto LFCHRa
LFCHR	if character is a LF, goto ERR1
LFCHRa	set up dispatch
DISPC	go do it
	goto EXIT
ERR1	send out "BAD"
	goto EXIT



Q8       if character is  
          LF, goto Q9

          if character doesn't match, goto Q9

          save new status

          return 1 from ESC1 to  
          get next character

Q9       if there is more to match,  
          goto Q6

          goto ERR1



### 8.2.2.1.3.2 Command execution

Local commands interpreted by the TIP subroutine ESC1 cause the TIP itself to take the actions noted below. Most generally, commands affect either local terminal handling functions or network connection functions. Where parameters or other information are required it is so noted. The commands are listed in alphabetical order and cross reference other commands as appropriate.

#### ABORT LOGIN

Abort the outstanding initial connection protocol.

#### BINARY INPUT END

Leave 8-bit binary input mode; this command must be given from another device since commands are not recognized in binary input mode.

#### BINARY INPUT START

Enter 8-bit binary input mode.

#### BINARY OUTPUT END

Leave 8-bit binary output mode.

#### BINARY OUTPUT START

Enter 8-bit binary output mode.

#### CLEAR DEVICE WILD

Set device to be unwild; i.e., stop accepting RFC's from any Host.

#### CLEAR INSERT LINEFEED

Stop inserting linefeed after carriage-return.

#### CLOSE

Close all outstanding connections for this device.

#### DEVICE CODE 37

Establish parity computation for Model 37 Teletype for output to this device.

#### DEVICE CODE ASCII

Establish code conversion for an ASCII terminal.

#### DEVICE CODE EXTRA-PADDING

Establish code conversion for a terminal with slow CR; i.e., supply padding for correct carriage control.



DEVICE CODE OTHER-PADDING  
 Establish code conversion for a line printer; i.e., supply padding for correct carriage control.

DEVICE RATE #  
 # is a 13-bit code specifying hardware rate and character size settings for the device commanded.\*

# DIVERT OUTPUT  
 Capture device # and divert this terminal's output to it.

ECHO ALL  
 Commands the TIP to perform local TIP-generated echo--TIP echoes everything.

ECHO HALFDUPLEX  
 Commands the TIP to expect terminal-generated echo--TIP echoes nothing.

ECHO LOCAL  
 Send the Telnet "ECHO LOCAL" character and perform an internal E A.

ECHO NONE  
 Commands the TIP to expect remote Host-generated echo for data--TIP echoes commands only and not data.

ECHO REMOTE  
 Send the Telnet "ECHO REMOTE" character and perform an internal E N.

FLUSH  
 Delete all characters in this device's input buffer.

# GIVE BACK  
 Release control of captured device #.

HOST #  
 Simultaneous "@S T H" and "@R F H"; manual initialization of send and receive Host parameter to #.

INITIAL CONNECTION PROTOCOL  
 Start the initial connection protocol.

INSERT LINEFEED  
 Commands the TIP to insert linefeed after carriage-returns.

- - - - -  
 \* # denotes a decimal number unless otherwise stated.



INTERCEPT #  
 Use # as TIP command character instead of 64 [i.e., @].

INTERCEPT ESC  
 Leave 7-bit binary mode; this command must be given from another device since a device in 7-bit binary mode ignores commands.

INTERCEPT NONE  
 Enter 7-bit binary mode; the TIP will ignore commands given by this device.

LOGIN #  
 Start the initial connection procedure with Host # to get Telnet connections--equivalent to "@S T H" followed by "@R F S 1" followed by "@I C P".

M # #  
 Mag tape command # with argument #.

NETWORK-VIRTUAL-TIP-EXECUTIVE  
 Connects the user to the Network-Virtual-TIP-Executive.

PROTOCOL BOTH  
 Simultaneous "@P T T" and "@P T R".

PROTOCOL TO CLOSE RECEIVE  
 Manually initiate protocol to close the receive connection.

PROTOCOL TO CLOSE TRANSMIT  
 Manually initiate protocol to close the transmit connection.

PROTOCOL TO RECEIVE  
 Manually initiate protocol to open a receive connection.

PROTOCOL TO TRANSMIT  
 Manually initiate protocol to open a transmit connection.

RECEIVE FROM HOST #  
 Establish Host # parameter for manual initialization of both send and receive Host.

RECEIVE FROM SOCKET #  
 Establish socket # parameter for manual initialization of the receive connection--socket # is given in octal.



RECEIVE FROM WILD  
Equivalent to "@R F S <any>"; Host remains as specified.

RESET  
Reinitialize a particular TIP port.

RESET NCP  
Resets NCP of the Host parameter associated with this device.

SEND BREAK  
Send the Telnet "BREAK" character.

SEND COMMAND  
Send the command escape character.

SEND SYNC  
Send the Telnet "SYNC" character and an "INTERRUPT SENDER" message.

SEND TO HOST #  
Establish Host # parameter for manual initialization of the transmit connection.

SEND TO SOCKET #  
Establish socket # parameter for manual initialization of the transmit connection--socket # is given in octal.

SEND TO WILD  
Equivalent to "@S T S <any>"; Host remains as specified.

SET DEVICE WILD  
Equivalent to the commands "@R F H <any>", "@S T H <any>", "@S T S <any>", and "@R F S <any>", and, in addition, leave these in effect after a connection is closed.

TRANSMIT EVERY #  
Send off the input buffer at least every #th character where 0 <# <256.

TRANSMIT NOW  
Send off the input buffer now.

TRANSMIT ON LINEFEED  
Send the input buffer every time a linefeed is encountered.

TRANSMIT ON MESSAGE-END  
Send the input buffer every time an end-of-message is encountered.



#### 8.2.2.1.4 Rate initiation for "hunting" devices

The HUNT routine determines the rate of a device. Certain TIP ports may always have the same devices attached to them, such as line printers, and may be pre-initialized to the particular requirements of those devices. Other TIP ports, however, will be used by very simple devices or by different devices, as in the case of modems: these ports are called "hunting." The first character typed on such a device should be the hunt character for that device (see TIP User's Guide). Hunting devices are initially (and after an @R command) set to a nominal rate of 134.5 baud; the expected character will thus vary depending on the actual rate of transmission. The HUNT routine compares the first character with the various possibilities to determine the correct rate.



HUNT        if this is not really  
             a hunting device, goto ESC2

             compare character with  
             expected responses

             if no match, goto HUNTa

             set up the right  
             rate & code

             adjust the table dispatch  
             accordingly

             send a HELLO message  
             to the device

             goto DOTN

HUNTa       wait for another character,  
             try again

             goto DOTN



#### 8.2.2.1.5 Input Conversion

##### 8.2.2.1.5.1 EBCDIC to ASCII Conversion Logic

At present the TIP does only one input conversion, from EBCDIC to ASCII. This section discusses the logic for converting from EBCDIC to ASCII for four types of PTTC and four types of Correspondence model 2741 terminals.

The EBCDIC to ASCII code conversion is handled by the routine called IBMIN using the main conversion tables labeled TAB1 and TAB1P and the auxiliary tables labeled TAB2, TAB3, and DISPIN, along with some state information in the tables NN and M.

The TAB1 conversion table is for the correspondence EBCDIC to ASCII conversion and is 128 elements long. The first half of TAB1 is used for direct table lookup of the ASCII equivalents of the lower case correspondence EBCDIC characters, and the second half of TAB1 is used for the upper case correspondence EBCDIC characters. The individual elements in TAB1 contain either the direct ASCII equivalent of the EBCDIC character to be converted, a pointer to the auxiliary conversion table TAB3, or an offset with which to dispatch through the address table DISPIN. If the preceding character was a quote ("), the character looked up in TAB1 is used as the index for a further lookup in the retranslation table TAB2, or the character looked up in TAB1 is mapped into some other character in TAB1.

The TAB1P conversion table is used identically to TAB1 except for ITTC EBCDIC characters.

The detailed logic of IBMIN follows:



IBMIN      get input character  
             and save it  
             (in IBCHAR)

            if line is in output mode, go to IBMQ7

            get upper/lower case bit  
             for terminal and append  
             it to left of character;  
             save result (in MODEL T)

            get model of terminal  
             and use it to select table  
             to access (TAB1 for Correspondence,  
             TAB1P for PTTC)

IBMQ1      pull character out of correct  
             position in correct table

IBMQ2      save character (in IBDATA)

            if character special  
             (>200), goto IBMQ6

            if last character received  
             was a quote, goto IBMQ3

            increment head position  
             counter

            get saved character  
             (from IBDATA)

IBMQ9      pass character on

            return from IBMIN



IBMQ3      mark that last  
            character received was  
            not quote

            if character = 140, goto IBMQ10

            if character >140, goto IBMQ5

            if character >37, goto IBMQ4

IBMQ10     character input has no  
            translation, skip it

            goto DOTN

IBMQ4      build pointer to access  
            character in retranslation  
            table (TAB2)

            goto IBMQ1

IBMQ5      if character >172, goto IBMQ10

            character was a lower case  
            letter preceded by quote

            map character into control  
            lower case letter

            goto IBMQ2



IBMQ6      if dispatch through DISPIN  
            is called for (character >360),  
            goto IBMQ8

            if character is a shift up  
            character (character = 360),  
            goto INUC

            character requires lookup in  
            an auxiliary table

            build pointer to auxiliary table  
            (TAB3) based on terminal model and type

            goto IBMQ1



IBMQ8      dispatch on character through  
DISPIN (to INBS, INLC, INNL, INTAB,  
INCC, INDQ, INLF, or INERR)

IBMQ7      If character is a circle-D, mark  
line in input mode

goto IBMQ1Ø

INUC      prepare a 1

goto INUCa

INLC      prepare a Ø

INUCa      jam Ø or 1 in NCASE

goto IBMQ10



INLF        mark that last character  
             was not quote

             increase null counter  
             by a bunch (call UPNULL)

             pick up a linefeed

             goto IBMQ9



INDQ       complement mark indicating whether  
             last character received was quote

             increment head position  
             counter

             if this is not the second of a  
             pair of double quotes, goto IBMQ10

             pick up a quote

             goto IBMQ9



INBS        if last character was not quote,  
             goto INBS2

             clear mark that last  
             character was quote

             goto IBMQ1Ø

INBS2       subtract one from head  
             position counter if head  
             not at left margin

             pick up a backspace

             goto IBMQ9



INNL        zero head position  
             counter

             increase null counter  
             (call UPNULL)

             mark that last character  
             was not quote

             mark that carriage  
             return received

             pick up carriage-return

             goto IBMQ9

INCC        if attempting to enter output mode,  
             goto INC2

             mark that line is attempting to enter  
             input mode

             restart output [to get circle-C sent]

             goto INC4

INC2        unblock output [clear NHOLD]

INC4        pick up a line feed

             goto IBMQ9



INTAB      mark that last character received  
            was not quote

            increment null counter  
            a little

            increment head position  
            to next multiple of 8

            pick up tab

            goto IBMQ9



#### 8.2.2.2 MLC Output (OUTINs)

CLKOI      swap buffers and  
            restart OI

            put a "device Ø" at end  
            of buffer

            save address of end of buffer in PSOI

            call OI

            return from CLKOI

OI  
OIL2      pickup next device number and  
            dispatch to one of LCHAR, NCHC,  
            NCHAR, ECHL, ECHR, or return from  
            OI (only device Ø does the latter).



```

LCHAR      call LINBSY

            if in middle of typing
            something, goto LAST1

            if any ERROR2 errors are pending,
            goto SETOI2

            if any ERROR errors are pending
            (besides "CLOSED", "T", "R", or
            "memory bits"), goto SETOI

            if net data is waiting, goto NEWBUF

            if there are any other errors pending,
            goto SETOI

            if terminal is not EBCDIC, goto LCHAR3

            if terminal is not in output mode, goto
            LCHAR3

            mark as "turning around"

LAST8      set delay timer and
            send a circle-C

            goto OIL1

LCHAR3     mark terminal inactive

            if device is not high speed (>2400 baud),
            goto OIL1

```



increment number of allowed extra OIs

if this was not an "added" OI, goto OIL1

clear memory of extra OI [ONMOR]

goto OIL1

NEWBUF      mark to send allocate

set up pointer to proper half of  
buffer and set up byte count

if not doing commands from net,  
goto NEWBUFa

set to dispatch to CCHAR

goto NEWBUFb

NEWBUFa      call DIRCHK

if conversion or CR timing is required,  
set dispatch to NCHC

if conversion or CR timing is not  
required, dispatch to NCHAR

NEWBUFb      dispatch to NCHC, NCHAR, or CCHAR



NCHC        get next character

if character is a TELNET  
character, goto SPBYTE

if code conversion is needed, call IBMOUT  
or GENPAR, as appropriate

if special CR control is needed, call ODEC,  
MEMRX, or SLOWCR, as appropriate

goto NCH2



NCHAR      get next character

            if character is a TELNET  
            character, goto SPBYTE

NCH2        format character for MLC

            if not searching for a DM,  
            goto NCH2a

            if not typing net traffic,  
            goto NCH2a

            throw character away

            goto SFUDGE



NCH2a      send character to MLC

NCH3      if more output is to follow,  
            goto OIL1

            set dispatch to LCHAR

OIL1      step to next OI  
            device number

            goto OIL2



#### 8.2.2.2.1 2471 Line Control

- A) Keyboard is unlocked, TIP is in input mode accepting data (NDIR=NTURN=0). One of two things eventually happens:
- 1) A Circle-C comes in (because a CR or ATTN was typed). We immediately revert to input mode by marking the line in "output turning" (NDIR=1, NTURN=1). OI will notice this state and will send a Circle-C to the 2741. The 2741 will then eventually unlock its keyboard and it will then send a Circle-D which will cause the line to be back in input mode.
  - 2) Some output comes along. NBREAK is set and the line is held open. After an appropriate wait, we send a char of "all mark" and set the line to "input turning" (NDIR=0, NTURN=1). OI will then send a Circle-D and mark the line to be in output mode. Output may then proceed.
- B) Keyboard is locked, output is in progress (NTURN=0, NDIR=1). One of two things may happen:
- 1) There is no more output to send. The line is marked as in "output turning". The same code as for A.1, above, will send a Circle-C, and the eventual Circle-D will put the line into input mode.
  - 2) A Break comes in (user hit ATTN). NHOLD is set and then proceed as in B.1. NHOLD will prevent any output from happening (i.e., you can only go down the A.2 path if hold is clear). NHOLD is cleared by the input of a Circle-C.



DIRCHK    if device is not EBCDIC,  
          return from DIRCHK

          if device is in output mode,  
          return from DIRCHK

          send reverse break and mark  
          device as "turning around"

          goto OIL1



```

LINBSY    if device is not EBCDIC,
          return from LINBSY

          if is not turning around,
          holding off output, or
          timing a reverse break, return
          from LINBSY

          if device not in "input turning
          around to output" mode,
          goto LINBSYa

          mark in output mode and
          send a circle-D

          goto OIL1

LINBSYA   if timing a reverse break
          or holding off output,
          goto LCHAR3

          now turning from output to
          input

          if delay time  $\neq 0$ , goto LCHAR3

          goto LAST8

```



MIFAST     If device is synchronous or its  
            output rate is  $\leq 2400$  baud, return

            set up INDMAX to the address of a word  
            containing the number of parallel OIs  
            required to achieve full speed

            give skip return

FASTER     if device is not high-speed, return

            if this is already an "added" OI goto  
            RESMER

            if an OI has already been added during  
            this pass through OI, return

            if device is already operating at full  
            speed, return

            count one less OI needed for full speed

            add an extra OI for this terminal on  
            the end of the OI table

            return

RESMOR     clear memory that an OI has been added

            return



#### 8.2.2.2.2 TELNET Protocol Handler

```
SPBYTE    if in binary output
           mode, goto NCH2

           if character is an IAC,
           goto SPIAC

           if character is "command from
           net", goto NETCOM

           if character is not an "echo remote",
           goto SPBYTEa

           call FIXECH(FDX)

           goto SFUDGE

SPBYTEa    if character is not an "echo
           local", goto SPBYTEc

           call FIXECH(HDX)

           goto SFUDGE

SPBYTEc    if character is not a DM,
           goto SFUDGE

SPBYDM     bump INS/DM count

SFUDGE     set OI to reprocess this device
           (i.e., step to next character)

           goto NCH3
```



AD-A108 103

BOLT BERANEK AND NEWMAN INC CAMBRIDGE MA  
THE TERMINAL INTERFACE MESSAGE PROCESSOR PROGRAM.(U)  
NOV 73

F/G 9/2


DAHC15-69-C-0179

UNCLASSIFIED


TECHNICAL INFORMATION-01

NL

2-3  
A 08-04







MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A



SPIAC	get next byte  if next byte is WILL, goto WILL  if next byte is DO, goto DO  if next byte is DM, goto SPBYDM  otherwise, goto SFUDGE
WILL	if no room in buffer, throw away next byte and goto SFUDGE  put IAC DONT in input buffer  goto SPIACa
DO	if no room in buffer, throw away next byte and goto SFUDGE  put IAC WONT in input buffer
SPIACa	copy next byte into input buffer  call SENDIT  goto SFUDGE



NETCOM     set "commands coming from  
             net" bit

             reset dispatch to  
             CCHAR

             dispatch to CCHAR

CCHAR       get next byte

             if no more, goto CCHARa

             if byte is CR, goto CCHAR

             pass character to command  
             processor

             if command not completed,  
             goto CCHAR

             clear "commands from net"  
             bit

CCHARa      reset dispatch to LCHAR  
             and dispatch to LCHAR



#### 8.2.2.2.2.1    FIXECH

The following routine, FEEXCH, is also called by the code for the user commands which set the echoing mode; however, the inclusion of the routine with the preceeding TELNET echo command code seems as natural as including it with the command code.



FIXECH(mode)    if input is not currently  
going to network, return from FIXECH

set new input dispatch  
from mode

return from FIXECH



8.2.2.2.3 Echoes

ECHL      call LINBSY  
  
            call DIRCHK  
  
            reset DISPATCH to ECHR  
  
            send ECHWD1  
  
            goto OIL1

ECHR      call LINBSY  
  
            call DIRCHK  
  
            reset dispatch to LCHAR  
  
            send ECHWD2  
  
            goto OIL1



#### 8.2.2.2.4 Messages to devices

The routines SETOI and SETOI2 are used to detect if there are any bits set in ERROR (SETOI) or in ERROR2 (SETOI2). If a bit is set, a pointer and byte count for the associated error message are retrieved and passed to the terminal output routine. SETOI and SETOI2 are called by the MLC clock interrupt routine. The only thing less than straightforward about these routines is the handling of the ERDED2, EROPN2, and ERCLS2 bits by SETOI. These bits are where memory is kept of the fact that a "DEAD", "OPEN", or "CLOSE" message was recently printed, and are cleared when there are no "real" bits left in ERROR. Also, if both the "T" and "R" bits are set simultaneously, both are cleared. Of course, the ERDED2, EROPN2, and ERCLS2 bits are prevented from themselves causing a message to be printed since they actually represent no message.

ERDED2 is set by the routine DEAD when either a "HOST DEAD" or "NET TROUBLE" message is set to be printed. Its purpose is to cancel the "REFUSED" message to prevent "DEAD REFUSED" when logging to a dead Host, if the "REFUSED" comes soon enough after the "DEAD".

EROPN2 and ERCLS2 are set by ERRTTEL to remember when an "OPEN" or "CLOSED" was recently printed, in order to prevent the "OPEN OPEN" or "CLOSED CLOSED" message when "CLOSED" or "OPEN" is printed but "R" and "T" are canceled because both are there, but they didn't arrive together so another "CLOSED" or "OPEN" is present.



SETOI      build pointer to base of correct table  
             depending on whether error is mag tape  
             error or not

             if both "T" and "R" bits are not set  
             in ERROR, goto SETOIa

             clear both "T" and "R"  
             bits from ERROR

             goto LCHAR

SETOIa      if no bits are set in ERROR besides  
             ERDED2, EROPN2, and ERCLS2 "memory  
             bits", goto SETOIB

             get the first non-memory bit  
             which is set

             if no other bits are set, goto SETOIC

SET6        get a pointer to the  
             associated error message  
             and its byte count

             goto LAST2

SETOIB      clear ERDED2, EROPN2, and ERCLS2  
             "memory bits"

             goto LCHAR



SETOIc    clear first bit in ERROR  
          which was found set

goto SET6

SETOI2    build a pointer to correct  
          table for ERROR2 errors

find the first bit  
which is set in ERROR2

clear bit

goto SET6



The three routines ERRTEL, HOLLER, and HOLL2 are used to set flags which the terminal output routines detect and then print the indicated message on the TIP terminal. Two words of message flags are associated with each device; these are in the tables ERROR and ERROR2. HOLLER sets flags in ERROR; HOLL2 sets flags in ERROR2. ERRTEL is called rather than HOLLER for those messages which may have an associated "T" or "R", e.g., "OPEN T". The handling of the "CLOSED" and "OPEN" messages by ERRTEL is a little complicated. If either of these bits is set in the call to ERRTEL, the associated "memory bit," ERCLS2 or EROPN2, is set to remember that "CLOSED" or "OPEN" was just printed. Making use of this memory, if ERCLS2 or EROPN2 is set when ERRTEL is called with a "CLOSED" or "OPEN", that bit is cleared to prevent two "CLOSEDs" or "OPENS" from being printed in a row. This is done by clearing the "OPEN" or "CLOSED" bit in the argument to ERRTEL if the associated memory bit is set before the argument is passed to HOLLER.



HOLLER    OR bits in argument  
          to HOLLER into ERROR

          set CR-LF bit in ERROR

          return from HOLLER

HOLL2     OR bits in argument to  
          HOLL2 into ERROR2

          call HOLLER with  $\emptyset$  argument  
          to set CR-LF bit in ERROR

          return from HOLL2



ERRTEL(X) if neither CLOSED-bit or  
OPEN-bit set in X, goto ERRTELa

for whichever of the CLOSED or  
OPEN bits is set in X, set the associated  
memory bit, ERCLS2 or EROPN2, in X

for whichever of the CLOSED  
or OPEN bits was set in X, if the associated  
memory bit, ERCLS2 or EROPN2, is set,  
clear the CLOSED or OPEN bit in X

goto ERRTELb

ERRTELa if ERRTEL was called by a "T  
routine," OR T-bit into X

if ERRTEL was called by an  
"R routine," OR R-bit into X

ERRTELb call HOLLER with argument X to  
set bits in ERROR

return from ERRTEL



#### 8.2.2.2.5 Output conversion

##### 8.2.2.2.5.1 ASCII to EBCDIC Conversion Logic

This section discusses the logic of converting from ASCII to EBCDIC (TIP to terminal) for four types of PTTC and four types of Correspondence model 2741 terminals.

The ASCII to EBCDIC code conversion is handled by the routine called IBMOUT using the main conversion tables labeled CVTB and CVTBP and the auxiliary conversion table SCVTB, along with some state information in the tables IN and M.

The CVTB conversion table is for the ASCII to Correspondence EBCDIC conversion and is 128 elements long, suitable for direct indexed access by the ASCII character to be converted. The individual element in CVTB either gives the direct conversion to a Correspondence EBCDIC character, indicates that a quote (") character should be printed before the Correspondence EBCDIC character also given, or indicates an entry in the auxiliary table SCVTB which contains the proper Correspondence EBCDIC character and perhaps further indications. Each entry in the auxiliary table SCVTB has four subelements, one for each of the four types of Correspondence terminals. The CVTB entries also indicate the proper case for the Correspondence EBCDIC character to be printed.

The CVTBP table is identical in form and use to the CVTB table except that it is used for ASCII to PTTC EBCDIC conversions.

The detailed logic of IBMOUT follows:



IBMOUT      save ASCII character to  
              be converted (in CHARIB)

             if the previous character printed  
              was a carriage-return (MGOTR  $\neq$  0), goto P03

P04          get base of proper conversion table,  
              CVTB for Correspondence, CVTBP  
              for PTTC

             build pointer to converted character

P02          save pointer (in IBMT2)

             get converted character  
              and save it (in HOLDIT)

             if auxiliary lookup is to be done  
              and if character not to be preceded  
              by quote, goto P01

             if character is to be preceded  
              by quote, goto P11

P13          if case matters for character  
              to be printed, goto P09

             mark that quote was not last  
              character sent (NQUOTE  $\leftarrow$  0)

             increment head  
              position counter

             get character to be printed  
              (from HOLDIT); mask character  
              down to 7 bits

             goto NCHAl (to print character)



P09        if terminal's case is already  
             correct, goto P08

             if case should be upper  
             case, goto P10

             complement case  
             (NCASE+NCASE)

             goto NCHA0 (to print  
             lower case character)

P10        complement case  
             (NCASE+NCASE)

             goto NCHA0 (to print  
             upper case character)



P11       if the last character printed  
          was a quote (NQUOTE  $\neq$  0), goto P13

          if terminal's case is already  
          upper case, goto P10

          increment head  
          position counter

          mark that last character sent  
          was quote (NQUOTE+1)

          build a proper quote  
          character for model and type 2741

          goto NCHA0 (to print quote)

P01       if character to be converted  
          is an ASCII carriage-return, linefeed,  
          or tab, goto P01A

          if character to be converted is  
          an ASCII backspace, goto OIBS

          build pointer to the auxiliary table  
          SCVTB based on the terminal  
          type and the character to be converted

          goto P02



P03        if the character to be converted  
              is a linefeed, goto P05

             if the head position is not  
              zero, goto P14

             mark that last character  
              sent not a carriage-return (MGOTR←0)

             goto P04

P14        decrement terminal  
              head position

             goto NCHA0 (to print  
              backspace)

P05        if enough nulls have  
              been sent to terminal  
              (NNULL = 0), goto P15

P17        decrement count of nulls to be  
              sent to terminal (NNULL←NNULL - 1)

             if enough nulls have not yet been  
              sent to terminal, goto P06

             mark that last character sent was  
              not a carriage return

             goto NCHA4 (to send a null to terminal)



P15        clear head position counter  
          after first noting its value

          if head was so far out extra  
          nulls need to be sent, goto P15a

P15b       goto NCHAØ (to print a new line)

P15a       put large value in counter  
          of nulls to be sent

          goto P15b

PØ6        goto NCHAØ (to send a  
          null terminal)

PØ1A       if character to be printed  
          is a tab, goto OITAB

          if character to be printed  
          is a linefeed, goto OILF

          mark that last character printed  
          was a carriage return (MGOTR+1)

          goto SFUDGE



OIBS        if head position counter  $\neq$  0,  
             goto OIBSa

OIBSb       goto NCHA4 (to print a  
             backspace)

OIBSa       move head position  
             counter back

             goto OIBSb



OILF        if there is not a null character to be  
             sent to the terminal, goto P17

             mark that a null character  
             should be sent to terminal

             goto NCHAØ (to print a linefeed)



OITAB      if there is null character to  
             be sent to the terminal, goto P17

             increment the head position  
             counter by a bunch

             increment number of null characters  
             to be sent to terminal by a bunch

             goto NCHAØ (to print a tab)



#### 8.2.2.2.5.2 Slow Carriage Return

SLOWCR save character to be printed  
(in SLOWCH)

if a carriage return just  
sent, goto SLOWCRa

if this character is a  
carriage-return, goto SLOWCRb

SLOWCRc add 1 to head position

goto NUN4 (to print character)

SLOWCRb mark that carriage-return  
just sent

add a large constant to  
the head position

goto SLOWCRc



SLOWCRa    build a constant which is  
              function of device rate

             subtract this constant from  
              head position

             if head is at  
              left margin, goto SLOWCRd

SLOWCRe    update head position

             if this character is a  
              linefeed, goto SLOWCRc

             goto NCHAØ (to print rubout)

SLOWCRd    zero head position

             clear just sent  
              carriage-return bit

             goto SLOWCRe




#### 8.2.2.2.5.3 Even Parity

The even parity calculation routine, GENPAR, calculates a character's parity with three successively smaller shifts followed by exclusive-or's. The effect of this is to successively "fold" the character on itself until only the character's parity is left. The parity is then appended to the original character and the character with parity is passed to NCH4 for dispatch to the correct carriage-return padding routine. The logic of GENPAR is then, simply:

```
GENPAR    save character
          compute parity of character
          append parity to character
          goto NCH4
```

For help in reading the GENPAR code, the character folding takes place as follows.







#### 8.2.2.2.5.4. Line Printers

Line printers connected to the TIP frequently require special padding characters after carriage-returns, form feeds, etc. The TIP possesses code to support two different brands of line printers, the ODEC printer and the Memorex printer, although a given TIP can only be configured with the code for one or the other but not both.



#### 8.2.2.2.5.4.1 MEMORX

The MEMORX routine is the output dispatch that handles carriage control requirements of the Memorex 1240 Communications Terminal (and any other compatible device). The padding is tailored to a rate of 600 baud. The "rules" follow:

- 1) a line must be at least 43 characters long; if it is not, padding is added before sending the carriage return;
- 2) contiguous line feeds must be separated by 3 characters;
- 3) a vertical tab is followed by 27 padding characters;
- 4) a form feed is followed by 215 padding characters.



```

MEMRX      if not outputting character, goto MEMNUL

            if character is LF, goto MEMRXa

            if character is CR, goto MEMRXb

            if character is FF, goto MEM4

            if character is VT, goto MEM4

MEMSVI      decrement line count;
            output character

            goto NCHA4

MEMNUL      if finished with padding, goto MEMA1

            decrement count; output rubout

            goto NCHAØ

MEMRXa      if last character was a LF, goto MEM4

            mark it LF

            goto MEMSV1

```



MEM4        set up padding count

goto MEMNUL

MEMRXb     if line is not already long  
enough, goto MEM4

MEMRXc     set up count for new line


goto MEMSV1

MEMA1      if character is not control character,  
goto MEMRXc

set up appropriate count

goto MEMSV1







#### 8.2.2.3 Background Timer (BTIME)

The background timer routine, BTIME, is called by the MLC clock interrupt routine to print nulls until the null counter is zero and then, if the device is a 2741 which is reverse breaking, to set the line turn-around flag.



```

BTIME      if one (2741) character time has not gone
           by, return from BTIME

           i←0

BTIME2     if output is in progress
           to device i, goto BTIMEa

           if there are
           sent to device i, goto BTIMEa

           decrement null counter

           if device i is not a 2741,
           goto BTIMEa

           if device i is not "reverse
           breaking", goto BTIMEa

           clear "reverse breaking" flag

           set "line turn around" flag

           call IBECHO to print null

BTIMEa     i←i+1

           if i ≠ 64, goto BTIME2

           return from BTIME

```



### 8.2.3 Background

The TIP background loop, BACK, is quite straightforward as is shown below; BACK is called by the IMP background loop.



BACK           if TIP should be initialized  
              (TIPFLG  $\geq$  0), goto BACKa

              call SLURP

              call MODEM C

              call BCKWAK

              call SENDW

              return from BACK

BACKa          mark that initialization is no  
              longer needed (TIPFLG $\leftarrow$ -1)

              call GOGGLE

              return from BACK



The routines BCKWAK and BCKSLP have a co-routine relationship. BACK calls BCKWAK to restart BCKSLP (and its subordinate routines) where it last left off. BCKSLP subordinate routines call BCKSLP to wait (sleep) until the next pass through BACK. BCKSLP is initially set to restart at BCKCHK.



BCKWAK     return from BCKSLP (to restart  
             BCKSLP where it last left off)

BCKSLP     return from BCKWAK

BCKCHK     call LOGGER

             call PROBCK

             call PENDIN

             if appropriate, call MTBACK

             call BCKSLP

             goto BCKCHK



### 8.2.3.1 Connection and Host Functions (PENDIN)

PENDIN is a subroutine called by the background loop. It checks all devices in round-robin fashion to see if they have pending any of the following: one, data to go to the net; two, an AIL event to be sent; three, miscellaneous requests to do such as interrupts, resets, echo reply, etc.; four, a request for news; five, replies to unsolicited messages. PENDIN serves as a wakeup for these jobs and takes appropriate action when it finds something to do. As a general comment, the TII packs control messages going to the same Host into the same Host/Host protocol message. Using this feature, PENDIN continues to check all devices after it has set up a control message and appends any others going to the same Host.



PENDIN     if there is nothing to do,  
             return from PENDIN

             init to the next device  
             in round-robin order

PEND1     set up dispatch table  
             based on flags; entry  
             is NOP or JMP

PEND3     if entry is JMP, goto PENDA

PEND4     if entry is JMP, goto PENDB

PEND5     if entry is JMP, goto PENDC

PEND6     if entry is JMP, goto PENDE

PEND8     inc. to next device

             if not finished cycling through all  
             devices, goto PEND3

             goto PENDUN



PEND7      send off any messages to the  
             IMP with a call to FIRE

return from PENDIN



8.2.3.1.1 Device Related functions

8.2.3.1.1.1 Transfer data to IMP

PENDA      if device does not have data to go,  
             goto PEND4

             call SENDIT and SENDW to try to get  
             it going

             goto PEND4



#### 8.2.3.1.1.2 Allocates

PENDB      if there is no need to send  
            an allocate for device, goto PEND5

            if device is not being diverted  
            to, goto PENDB1

            use capturing device's  
            buffers for ALLOC

PENDB1     if connection is closing  
            or closed, goto PEND5

            if connection not open  
            yet, goto PENDB2

            call SENDAB to try get  
            the interface

            if did not get interface,  
            goto PENDB2

            set up an  
            allocate message

            mark allocate  
            as sent

            goto PEND5



PENDB2    set bit to try  
          device later

goto PEND5



8.2.3.1.1.3 News

PENDE      if not trying to  
            get news, goto PEND8

            if tried all news  
            Hosts, goto PEND8

            call SENDAB to try  
            to get interface

            if did not get interface  
            goto PEND8

            send an RFC to  
            a news Host

            set up next Host  
            in list for next time

            goto PEND8



8.2.3.1.2 Host related functions

8.2.3.1.2.1 Send INS's

PENDC      if don't need to  
             send interrupt, goto PENDD

             if connection not  
             open, goto PENDD

             call SENDAB to try get  
             the interface

             if did not get interface,  
             goto PENDD

             set up an interrupt message

             goto PENDD



8.2.3.1.2.2 Send ERP's, RST's, and RRP's

PENDD call PENDD to send ERP, RRP, RST if  
needed and can for transmit side

call PENDH to send ERP, RRP, RST  
if needed and can for rcv. side

goto PEND6

PENDH call SDRP to try to  
send ERP's

call SDRP to try to  
send RRP's

call SENDRP to try to  
send RST's

return from PENDH



```

SND RP(A)  if Host is not marked as
           needing A sent, return from SND RP

           set up Host to send to for
           device Ø!

           call SENDAB to try to get
           interface to IMP

           if did not get interface, return from SND RP

           clear mark for Host saying A
           should be sent

           if A=ERP, goto SND RPa

           for all devices talking to this Host, close
           the connection if not already closed (calls
           SHUTDN) and print "CLOSED"

           build an A (RST or RRP) in IMP buffer
           with call to PUTLST

           return from SND RP

SND RPa    build an ERP in IMP buffer with
           call to PUTLST

           return from SND RP

```



8.2.3.1.2.3 Send CLS's for unsolicited RFC's and CLS's

PENDUN     if a CLS for an unsolicited  
             RFC or CLS has not been saved,  
             goto PEND7

             call SENDAB to get interface

             if did not get interface, goto PEND7

             clear the saved CLS just sent

             goto PEND7



### 8.2.3.2 Connection Control (PROBCK)

PROBCK is a subroutine called by the background loop. It checks the status of all connections (active or not) and sends "open" or "close" messages to Hosts if required. PROBCK uses the two connection tables PSTATE and QSTATE, respectively send and receive, which indicate status as follows:

- 0 = try to open
- 1 = RFC sent
- 2 = RFC received, try to reply
- 3 = solid connection
- 4 = try to close
- 5 = CLS sent
- 6 = CLS received, try to reply
- 7 = no connection



PROBCK     if flag not set, return from PROBCK

init counter; init index  
to 1st connection

goto PROB2

PROB3     increment counter; increment index

if not done all connection, goto PROB2

return from PROBCK

PROB2     if this connection does not  
need doing, goto PROB3

set flag to do PROBCK again

if transmit connection and data  
link blocked, goto PROB3

if receive connection and output  
active, goto PROB3

PROB1     try to get Host for  
control msg with call  
of SENDAB

if did not get interface, goto PROB3

if connection trying to close, goto PRO3

connection trying to open

if rcv. side, goto PRO3a



transmit side, TRYPRT←10

AC←code for STR

goto PRO5

PRO3      TRYPRT←0  
          AC←code for CLS

goto PRO5

PRO3a     TRYPRT←dev + 2

AC←code for RTS

PRO5      set up msg to Host

if not trying to close, goto PRO5a

call SHUTDN to close the connection

return from PROBCK

PRO5a     call FIRE to send the message

return from PROBCK



### 8.2.3.3 Initial Connection Protocol (Logger)

The TIP's logger can do the Initial Connection Protocol for only a single device at a time. Device requests to log are queued via the MDLOG bit. When the logger accepts a device, it will ICP to HOSTS over SOCKR1 and SOCKR2(!). To keep track of what it is doing, the logger uses two three-state flags, LOGS and LOGOPN. LOGS saves the internal state of the logger, while LOGOPN reflects the state of the remote logger.

The three states of LOGS are:

- 1) =0   LOGGER IS IDLE
- 2) =1   LOGGER HAS ATTEMPTED TO OPEN LOGGING CONNECTION
- 3) >1   LOGGER HAS ATTEMPTED TO CLOSE LOGGING CONNECTION

The three states of LOGOPN are:

- 1) =0   LOGGING CONNECTION NOT MADE
- 2) <0   LOGGING CONNECTION IS OPEN
- 3) >0   LOGGING CONNECTION IS CLOSED

LOGOPN is set by TESTOK (from GETCLS, GETSTR, GETRTS; from PROT; from SLURP).

The logger attempts to get the logging connection open and closed as quickly as it can, ignoring any data that comes in over the connection. Once the logging connection is dispensed with, the device is set wild and then the logger drops off the device.




The logger allows 500 "logger ticks" ( $\approx$  1800 MLC clock ticks) to complete its part of the ICP. Note that this time only runs from the beginning of the login sequence up to the closing of the logging connection. The device must fend for itself on getting




the data connections open, and the user must fend for himself waiting to get to the logger. All "abort login" does is to set the timer close to overflowing, thus doing nothing if the user is not yet on, or is already off, the logger. Login is also aborted by the disconnect code.

There follow some diagrams of portions of the logger logic, followed by a chart giving the logic as seen by the user.















#### 8.2.3.4 Send data to IMP

TILEAD     store second leader word in IMP buffer

set up destination in first word  
in IMP buffer

mark as not last  
packet of message

fake interrupt of Host to IMP

return from TILEAD



#### 8.2.3.4.1 Link 0

SENDAB     if SENDAB is already using interface (GOING<sub>2</sub> 0),  
             goto SENDABa

             if anything else (e.g., data) is already using  
             interface (TIGOF  $\neq$  0), return 1  
             from SENDAB

             if link blocked to destination Host, return  
             1 from SENDAB

             block link

             GOING<sub>2</sub>-1

SEND6       for all devices clear send-allocate-  
             to-Host-bit as unblocked control link  
             indicates no un-RFNMed allocates to  
             this Host

             call TILEAD to send leader  
             without last packet bit set

SENDABb     if IMP is not ready for more  
             (TIGOF  $<$ -1), call BCKSLP to wait a while  
             and then goto SENDABb

             call PUT2 to fill in first three words  
             of extended Header

             return 2 from SENDAB



SENDABa    if to correct destination, return  
            2 from SENDAB

            return 1 from SENDAB

FIRE        if GOING < 0, return from FIRE

            GOING ← -1

            put padding in IMP buffer

            fake interrupt to Host-to-IMP

            return from FIRE



#### 8.2.3.4.2 Not link Ø

Messages from terminals (i.e., messages not using link Ø) are sent from the TIP to the IMP by a set of routines. These are SENDIT, SENDW, SENDOF, MOVWRD, GETBUF, TOHOST, and TILEAD. The control structure of these routines is that SENDIT is called at clock level to lay claim to the TIP-to-IMP interface for a device. SENDW is called in the background loop and has a co-routine relationship to SENDOF. If a device has laid claim to the TIP-to-IMP interface, SENDW checks to see if the interface is not in use by the link Ø code, SENDAB. The interlock between the link Ø use of the interface and the data link use of the interface is the flag TIGOF. If SENDW can get the interface, it jumps into SENDOF. SENDOF does what it can about copying the data characters from the device input buffers to the IMP, debreaking via a call to SENDOF when it's necessary to wait for some reason. SENDOF calls TILEAD (also used by SENDAB) to give a leader to the IMP, calls GETBUF to get an IMP buffer to fill with data, calls MOVWRD to fill the buffer, and calls TOHOST to pass the filled buffer to the IMP.



SENDIT    if some device has not already  
          got the TIP-to-IMP interface (DEVYCE  $\neq$  0),  
          capture interface for current device  
          (DEVYCE+device)

          make all the buffer visible

          set the overrun flag

          return from SENDIT



SENDW      if no device is giving stuff to the  
            IMP (DEVYCE  $\neq$   $\emptyset$ ), return from SENDW

            if IMP is busy (TIGOF = -1), return  
            from SENDW

            if IMP is expecting beginning of message  
            (TIGOF < -1), goto SENDL1

            return from SENDOF (restart SENDOF where  
            it last left off)



SEND0F      return from SENDW

SENDL1      if link is blocked, return  
             from SENDW

             if there is no message allocate,  
             return from SENDDW

             subtract 1 from the message  
             allocate

             if there is no bit allocate,  
             goto BFAIL2

             clear OVERRUN flag (MDOVER←0)

             call SHRINK to update character count

             if there is nothing in the  
             input buffer to send, goto BFAIL2

             if bit allocate is big enough for all  
             the characters to be sent,  
             goto SENDL8

SENDL9      set overrun flag so rest  
             will be sent later

             if characters to be sent do not  
             fit in one message, goto SENDL1a



call TILEAD to send leader to IMP

build on extended header in  
IMP buffer

call MOVWRD repeatedly with successive  
characters from input buffer

call MOVWRD with padding

call TOHOST to close off message  
(last packet of message)

update bit allocate

return from SENDW

SENDL1a    set number of characters to be sent to  
             exactly 1 message

goto SENDL9

BFAIL2    add 1 back into message allocate

mark that device no longer using  
SENDOF (DEVYCE+Ø)

call SENDOF

BFAIL    return form SENDW



MOVWRD     save the word

if the IMP buffer is full,  
goto MOVWRDa

MOVWRDb     store the saved word  
in the buffer

increment the buffer fill pointer

return from MOVWRD

MOVWRDa     call TOHOST to give buffer to IMP  
(not last packet in message)

call GETBUF to wait until IMP has a  
new buffer ready

goto MOVWRDb



GETBUF    if IMP is not busy (i.e., has put up  
          another buffer), return from GETBUF

          call SENDOF to wait for a new  
          buffer

          return from GETBUF



TOHOST    set the last packet flag  
          as appropriate

          et the blocked link bit

fake interrupt to Host-to-IMP

return from TOHOST



#### 8.2.3.5 Accept Data From IMP (SLURP)

The routine SLURP is used to take messages from the IMP and to process them. The messages are of two main classes, irregular (IMP-to-Host control) messages which are processed by the routine IRREG, and regular messages. The regular messages in turn are of two classes, control messages on link 0 which are processed by the routine PROT, and data messages on links 3 through 65 which are processed by the routine DATABF. Of course various illegal messages may also arrive; these are discarded and reported as appropriate. The subroutine SDIS is used to sort out the message type and dispatch to the proper processing routine. The linkage between the rest of the background routines and the routines which will be described in this section is a co-routine linkage via the SLURP/SLURE co-routines.



SLURP

if the IMP has no data for the  
TIP, return from SLURP

return from SLURE (to restart SLURE  
where it last left off)

SLURE

save where left off for next  
call to SLURP

return from SLURP



FLUSHa    call NEXTBF to get next packet  
          in message

FLUSH     if this is not last packet in message,  
          goto FLUSHa

          call NEXTBF to get first  
          packet in next message

          call SDIS to dispatch on  
          message type

          call SLURE to pass control to other  
          background routines

          goto DATABF



NEXTBF     call H3OUIL to fake interrupt to  
             IMP-to-Host routine

             if the IMP has something for the TIP,  
             return from NEXTBF

             call SLURE to pass control to other  
             background routines while waiting for something  
             from IMP

             calls SDIS to dispatch on message type

             goto DATABF



```

SDIS      save link (in L2)

          save Host (in L1)

          if message is not a regular message
          from a real Host, goto IRREG

          save the Host/Host protocol byte count
          (in OUCNT1) and negative of byte count
          (in L4)

          if link number = 0/, goto PROT

          if link number = 1 or >65., goto BUGFA

          otherwise,  $3 \leq \text{link} \leq 65$  (or,  $1 \leq$ 
          device  $\leq 63$ )

          if message is not from Host from
          which it is expected, report error and
          goto FLUSH

          dispatch to magtape option if appropriate

          return from SDIS

```



BUGFA      if link  $\neq$  66, report an error

goto FLUSH



#### 8.2.3.5.1 Irregular Messages

The irregular messages the TIF receives from the IMP are handled by the routine IRREG. The handling of the irregular messages is fairly straightforward, as shown by the following detailed logic descriptions. One complication is the handling of RFNMs and INCOMPLETE TRANSMISSIONS which gets involved with Host/Host protocol allocates and the TIP's terminal input buffering logic.



```

IRREG      dispatch on message type

            if type >10., =3, or =6 (undefined or NOP),
            goto FLUSH

            if type =10. (INTERFACE RESET), report error
            and goto FLUSH

            if type =1 (ERROR WITHOUT ID), report error
            and goto FLUSH

            if type =8 (ERROR WITH ID), report error
            and goto FLUSH

            if type =2 (IMP GOING DOWN), goto IGD

            if type =5 (RFNM), goto IRFNM

            if type =7 (DESTINATION DEAD), goto DEAD

            otherwise type =9 (INCOMPLETE TRANSMISSION)

            report "INCOMPLETE TRANSMISSION"

            call UNBLK to unblock link

            if link is already unblocked, goto FLUSH

            if link is control link, goto IRINC3

IRINC1     scan through all devices looking for connections
            to Host which sent INCOMPLETE TRANSMISSION
            and marking allocates to be retransmitted as
            necessary--finally, poke allocate sender

            goto FLUSH

```



IRINC3 restore allocates for Host to what  
they were before last message was sent

goto IRFNM3



IGD      loop through all devices setting  
         IMP-GOING-DOWN error message bit

goto FLUSH



IRFNM call UNBLK to unblock link

if link was already unblocked, goto FLUSH

if link is control link, goto IRFNM1

flush the RFNMed characters from  
the input buffer

if no characters are left in  
input buffer, goto IRFNM4

relocate them to bottom of  
the input buffer

IRFNM4 adjust input buffer pointer so it points the  
beginning of the available space

IRFNM3 call SENDIT and SENDW to attempt to  
send any new stuff to be sent

goto FLUSH



DEAD     call UNBLK to unblock link

         if link is control link, goto DEAD2

         call SHUTDN to shut down one connection

         call SHUTDN to shut down other connection

         mark PSTATE to close one connection

         mark QSTATE to close other connection

         goto DEAD3

DEAD2    if nobody is using logger, goto FLUSH

         if not talking to dead guy, goto FLUSH

         clear logger

DEAD3    tell user "DEAD"

         goto FLUSH



```

UNBLK      if link  $\neq$  0, goto UNBLKa

            unblock the control link to this Host

            if link was not already unblocked, return
            from UNBLK

            report "EXTRA RFNM"

            return from UNBLK

UNBLKa     if link is 77 and if mag tape option, return
            from UNBLK

UNBLKb     search all devices for one using this link
            to this Host

            if done, goto UNBLKc

            if link not blocked, goto UNBLKb

            unblock link

            return from UNBLK

UNBLKc     report "EXTRA RFNM" error

            goto FLUSH

```



#### 8.2.3.5.2 Regular Messages

Regular messages come from the IMP in two forms, those on link zero (the Host/Host protocol control link) and those on data links (data messages for TIP terminals). The link 0 messages are processed by the routine PROT, and the data link messages are processed by the routine DATABF.



#### 8.2.3.5.2.1 Link Ø Messages

Link Ø is used for Host/Host protocol control messages. The handling of these Host/Host protocol control messages is done in five pieces:

- handling RFCs and CLSs
- handling ECOs and RSTs
- handling ALLOCATES
- counting INSS
- ignoring illegal commands and commands not handled by the TIP.

The logic for dispatching on the various commands and ignoring the illegal and unhandled commands follows:



PROT        if no commands in the message, goto NOPROT

            set up GET1 co-routine to  
            restart at GETNOP

PROTa       get next byte in message

            return from GET1 (restart GET1 where  
            it last left off)

GET1        if there are any bytes left in  
            message, goto PROTa

GETOUT      Poke PROBHO

            goto FLUSH

NOPROT      report reception of zero length  
            protocol message

            goto FLUSH



GETNOPa    call GET2 and GET1 to flush bytes  
            to the end of command

            call GET to get next character

GETNOP     dispatch on Host/Host protocol command type

            if ERR, RET, GVB, INR, ERP, RRP  
            or NOP, goto GETNOPA

            if RTS, goto GETRTS

            if STR, goto GETSTR

            if CLS, goto GETCLS

            if ALL, goto GETALL

            if INS, goto GETINS

            if ECO, goto GETECO

            if RST, goto GETRST



#### 8.2.3.5.2.1.1 Handling RFCs and CLSs

RFCs (Request for Connections) are handled by the GETRTC/GETSTR routine. CLSs (Closes) are handled by the GETCLS routine. RFCs and CLSs are driven by an eight-state finite-state machine for each device. The states are:

- 0 -- try to open
- 1 -- RFC sent
- 2 -- RFC received, try to reply
- 3 -- connection open
- 4 -- try to close
- 5 -- CLS sent
- 6 -- CLS received, try to reply
- 7 -- no connection

External events drive the finite-state machine into its even-numbered state. Every time the TIP finds a device in an even-numbered state, it immediately performs the function which allows it to move the device to the next sequential odd-numbered state.



GETRTS

GETSTR call SUCKS to get the socket numbers

save (in EXTRA) the link or byte size,  
depending on whether RTS or STR

call TESTOK to see if it's ok to act on RTS  
or STR; if not ok, goto TOOBAD

if the finite state machine for this  
connection is in states 2,3,4,5, or 6,  
report error and goto GETNOP

if state is 0 or 7, make state 1 and goto GETSTRa

if state is 1, make state 2

GETSTRa save first socket number (in  
SOCKS1 and SOCKS2)

if command is RTS, goto RTS



STR      set flag to send allocates to Host

complete bit allocate

poke PENALL to cause allocate  
to be sent

save Host in HOSTR

goto GETSTRb

RTS      save link and Host in HOSTS

GETSTRb call ERRTEL to print "OPEN"

poke PROBHO

goto GETNOP



TOOBAD if first "slot" in CLS sender  
is busy, goto TOOBADb

TOOBADa build a CLS in free slot

goto GETEC1

TOOBADb if other "slot" is busy, goto GETNOP

goto TOOBADa



```

TESTOK    if this device is looking
           for news, goto TE31

           if gender of connection is
           send, goto TE21

           if this device is not logging,
           error return from TOOBAD

           mark device to log

           goto GETNOP

TE21      if Host is wild, goto TE21a

           if Host does not match what
           expected, error return from TESTOK

TE21a     if socket is wild, good return
           from TESTOK

           if socket is not what's expected, error
           return from TESTOK

           good return from TESTOK

TE31      if socket is news socket,
           error return from TESTOK

           save Host, link, and sockets
           with device

           clear news bit

           good return from TESTOK

```

8/73

8.2.3.5.2.1.1-5



GETCLS call SUCKS to get socket numbers from message

call TESTOK to check if everything ok  
to start closing this procedure

if not ok, goto GETNOP

if connection is in state 0, 6, or 7,  
goto GETNOP

if connection is in state 5 or 1,  
goto GETCLSa

connection is in state 2, 3, or 4

put connection in CLS  
received state

goto STR4

GETCLSa call SHUTDN to clean  
things up

put connection in closed state

goto STR4



The following routine, SHUTDN, is called by GETCLS to clear up things associated with a closed connection. The routine is also called when a connection is closed because the Host went dead (by DEAD), because the Host sent a Reset (by SND RP), and the Host refuses the ICP (by PRO BCK). Consequently, the inclusion of SHUTDN under GETCLS is a little unnatural; however, under GETCLS is as natural as any other place.



SHUTDN if device is wild, reset sockets  
and Host to "<any>"

if shutting down send side, clear allocate  
counters and reset send link to Ø

if not shutting down send link, mark to  
not retransmit allocate

if device set to non-permanent  
@I N, reset escape to "@"

clear INS/DM count

return from SHUTDN



#### 8.2.3.5.2.1.2 Handling ECOs and RSTs

As explained earlier, the TIP handles Host/Host protocol ECO and RST on a "catch as catch can" basis.

GETECH call GET1 to flush byte to be echoed

pickup echo-reply bit

goto NEEDRP

GETRST pickup Reset-reply bit

NEEDRP OR in bit to proper flag by Host if not  
already set

poke PENOTH flag to cause ERP or  
RRP to be sent

goto GETNOP



#### 8.2.3.5.2.1.3 Handling ALLOCATES

Received allocates are processed by the routine GETALL.

GETALL save link (in ALINK)

save message allocate (in AM)

save bit allocate (in AH and AL)

save word allocate (in ALL)

if there is no device from this Host  
using this link, goto GETNOP

if connection for this device is not  
in state 2, 3, 4, or 5, goto GETNOP

call mag tape if appropriate

if bit allocate  $\leq 2^{16}$ , goto FIND5



FIND6    mark bit allocation as infinite

goto FIND8

FIND5    if newly received bit allocate will cause  
bit allocation to overflow, goto FIND6

add newly received bit allocate to  
bit allocation

add newly received message allocate  
to message allocation

call SENDIT and SENDW to send  
allocate if possible

goto FLUSH



#### 8.2.3.5.2.1.4 Counting INSs

Counting INSs is done by the routine GETINS in a completely straightforward manner.

GETINS if not  $3 \leq \text{link} \leq 65$ , goto GETNOP

increment the INS count for the device indicated  
by the link

goto GETNOP



#### 8.2.3.5.2.2 Messages Not On Link 0

Arriving messages which are not on link 0 contain data for output to devices. After a few checks for the proper format of the received messages, the data in the message is copied into the device's output buffer and, if necessary, output to the device is started.



DATABFa    get device number of device being  
             diverted to

             store device number  
             in OUDEV

DATABF    saved device number in OUDEV

             if device is diverting output,  
             goto DATABFa

             if there is no output buffer for  
             this device, goto FLUSH

             save max allocate which can be  
             sent (in MAXALI)

             if more data has arrived than device's output  
             buffer can hold, goto DATABFb

             set up to send allocation  
             equal to data received

DATABFc    if no data in message  
             received, goto NODATA

             Copy bytes of received message into  
             output buffer for device until message  
             end or packet end, whichever comes first.  
             If packet end comes first, call NEXTBF to get  
             next packet of message and continue copy.  
             When message ends, set mark to indicate  
             there is output for device (MIGOTO +1)

             call OUNEW to start output to device

             goto FLUSH



AD-A108 103

BOLT BERANEK AND NEWMAN INC CAMBRIDGE MA  
THE TERMINAL INTERFACE MESSAGE PROCESSOR PROGRAM (U)  
NOV 73

F/6 9/2

DAHC15-69-C-0179

UNCLASSIFIED


TECHNICAL INFORMATION-91

NL

3743  
A.00.01

END  
DATE  
FILMED  
4-82  
DTIC





MICROCOPY RESOLUTION TEST CHART  
NATIONAL BUREAU OF STANDARDS-1963-A



DATABFb report error

set up to send max allocation

goto DATABFc



#### 8.2.3.5.2.2.1 OUNEW

The following routine, OUNEW, is used to start output to a device, if it is not presently doing any and there is something new to go to the device. The routine is also called by MODEMC and consequently its description here under DATABF is not completely natural; however, here seems as natural as any other place.



OUNEW        if output is in progress,  
              return from OUNEW

mark device active

build device table consisting of  
a single device #: the terminal being  
started up, in the table set the "fake  
OI" bit (the sign bit).

lock interrupts & change PRIM

initialize # of "extra" OIs this device  
requires to achieve full speed [by  
calling IMAX]

call OI

restore PRIM

return from OUNEW



#### 8.2.3.6 Modem and LIU Control

MODEM C    if we have set up no line to  
            interrogate, goto MODEMa

            if this is a "lethargic" pass,  
            goto MODEMg [i.e. if DSFLAG is set]

            read LIU status

            if carrier not up, goto MODEMb

            mark that carrier is present (by clearing  
            MOCARR)

MODEM 8    clear MOHANG

            goto MODEMa

MODEMb    re-read LIU status

            if data set ready is up, goto MODEMa

            reset delay timer

            if carrier was not up last time,  
            goto MODEMa

            mark that carrier is down (set MOCARR)

MODEMh    set to drop data terminal ready

            call RESET to get the port unwound

            goto MODEM8



```

MODEMa    step to next device

          if next device is not Ø, go to MODEMi

          reset DSFLAG

          if lethargic pass timer [DSCLK] has not
          run out, goto MODEMi

          reset timer to one minute

          set DSFLAG

MODEMi    if output in progress, goto MODEMc

          if MLC input controller is to be
          reset, goto MODEMd

          if MLC output controller is to be
          reset, goto MODEMe

          restart output with call to OUNEW

          mark to raise data terminal ready
          next time

          goto MODEMc

MODEMd    get new input rate

          goto MODEMf

```



MODEMe      get new output rate

set "OI expected"

goto MODEMf

MODEMc      get current state of data terminal  
ready

MODEMf      output to MLC controller

return from MODEMc

MODEMg      read LIU status

if data set is not in the state of  
carrier data set low and data set  
ready high, goto MODEM8

complement MOHANG

if MOHANG is now 0, goto MODEMh

goto MODEMa



#### 8.2.4 MLC Output Interrupt Routine

The routine which services the MLC Output Interrupt is called TOUT. In addition to being called by the MLC Output Interrupt, TOUT is also called by the Clock Interrupt routine (at OOPS) to restart MLC output when necessary.



TOUT        save AC

             save keys

             if there is not output to  
             go, goto TOUTa

             set up an output from  
             the buffer with stuff in it

             switch to other buffer for  
             filling with more characters

             do output

TOUTa       restore keys

             restore AC

             enable interrupts


             return



#### 8.2.5 Magnetic tape option

There follows a block diagram for the TIP magnetic tape option. The magnetic tape option listing, attachment IV, should be studied along with the diagram.







### 8.3 Index to Detailed Descriptions

ADDLF	8.2.2.1.1-5
BACK	8.2.3-2
BACKA	8.2.3-2
BCKCHK	8.2.3-4
BCKSLP	8.2.3-4
BCKWAK	8.2.3-4
BFAIL	8.2.3.4.2-5
BFAIL2	8.2.3.4.2-5
BINCON	8.2.2.1.1-4
BINECO	8.2.2.1.1-4
BREAK	8.2.2.1.1-3
BTIME	8.2.2.3-2
BTIME2	8.2.2.3-2
BTIMEA	8.2.2.3-2
BUGFA	8.2.3.5-6
CCHAR	8.2.2.2.2-3
CCHARA	8.2.2.2.2-3
CLKOI	8.2.2.2-1
CLOCK	8.2.2-1
CLOCK4	8.2.2-1
CLOCKA	8.2.2-2
CONEEE	8.2.2.1.1-7
CONESC	8.2.2.1.1-7
DATABF	8.2.3.5.2.2-2
DATABFA	8.2.3.5.2.2-2
DATABFB	8.2.3.5.2.2-3
DATABFC	8.2.3.5.2.2-2
DEAD	8.2.3.5.1-6
DEAD2	8.2.3.5.1-6
DEAD3	8.2.3.5.1-6
DIRCHK	8.2.2.2.1-2
DISPC	8.2.2.1.3.1-7
DO	8.2.2.2.2-2
DOTN	8.2.2.1.1-2
DOTN2	8.2.2-1
DOTN2	8.2.2.1.1-2
ECHBEL	8.2.2.1.1-6
ECHL	8.2.2.2.3-1
ECHO	8.2.2.1.2-2
ECHR	8.2.2.2.3-1
EOM	8.2.2.1.1-6
EOMA	8.2.2.1.1-6
ERR1	8.2.2.1.3.1-7
ERRTEL	8.2.2.2.4-6



ERRTELA	8.2.2.2.4-6
ERRTELB	8.2.2.2.4-6
ESC	8.2.2.1.1-7
ESC1	8.2.2.1.3.1-2
ESC1A	8.2.2.1.3.1-3
ESC2	8.2.2.1.1-7
EXIT	8.2.2.1.3.1-4
FASTER	8.2.2.2.1-4
FEED	8.2.2.1.1-6
FIND5	8.2.3.5.2.1.3-2
FIND6	8.2.3.5.2.1.3-2
FIRE	8.2.3.4.1-2
FIXECH	8.2.2.2.2.1-2
FLUSH	8.2.3.5-3
FLUSHA	8.2.3.5-3
GENPAR	8.2.2.2.5.3-1
GET1	8.2.3.5.2.1-2
GETALL	8.2.3.5.2.1.3-1
GETBUF	8.2.3.4.2-7
GETCLS	8.2.3.5.2.1.1-6
GETCLSA	8.2.3.5.2.1.1-6
GETECH	8.2.3.5.2.1.2-1
GETINS	8.2.3.5.2.1.4-1
GETNOP	8.2.3.5.2.1-3
GETNOPA	8.2.3.5.2.1-3
GETOUT	8.2.3.5.2.1-2
GETRST	8.2.3.5.2.1.2-1
GETRTS	8.2.3.5.2.1.1-2
GETSTR	8.2.3.5.2.1.1-2
GETSTRA	8.2.3.5.2.1.1-2
GETSTRB	8.2.3.5.2.1.1-3
GOGGLE	8.2.1-2
HOLL2	8.2.2.2.4-5
HOLLER	8.2.2.2.4-5
HUNT	8.2.2.1.4-2
HUNTA	8.2.2.1.4-2
IBMCON	8.2.2.1.1-4
IBMECO	8.2.2.1.1-4
IBMEEE	8.2.2.1.1-4
IBMESC	8.2.2.1.1-4
IBMIN	8.2.2.1.5.1-2
IBMOUT	8.2.2.2.5.1-2
IBMQ1	8.2.2.1.5.1-2
IBMQ10	8.2.2.1.5.1-3
IBMQ2	8.2.2.1.5.1-2
IBMQ3	8.2.2.1.5.1-3
IBMQ4	8.2.2.1.5.1-3
IBMQ5	8.2.2.1.5.1-3
IBMQ6	8.2.2.1.5.1-4



IBMQ7	8.2.2.1.5.1-5
IBMQ8	8.2.2.1.5.1-5
IBMQ9	8.2.2.1.5.1-2
IGD	8.2.3.5.1-4
INBS	8.2.2.1.5.1-8
INBS2	8.2.2.1.5.1-8
INCC	8.2.2.1.5.1-9
INC2	8.2.2.1.5.1-9
INC4	8.2.2.1.5.1-9
INDQ	8.2.2.1.5.1-7
INLC	8.2.2.1.5.1-5
INLF	8.2.2.1.5.1-6
INNL	8.2.2.1.5.1-9
INTAB	8.2.2.1.5.1-10
INUC	8.2.2.1.5.1-5
INUCA	8.2.2.1.5.1-5
IRFNM	8.2.3.5.1-5
IRFNM3	8.2.3.5.1-5
IRFNM4	8.2.3.5.1-5
IRINC1	8.2.3.5.1-2
IRINC3	8.2.3.5.1-3
IRREG	8.2.3.5.1-2
LAST8	8.2.2.2-2
LCHAR	8.2.2.2-2
LCHAR3	8.2.2.2-2
LFCHR	8.2.2.1.3.1-7
LFCHRA	8.2.2.1.3.1-7
LINBSY	8.2.2.2.1-3
LINBSYA	8.2.2.2.1-3
MEM4	8.2.2.2.5.4.1-3
MEMA1	8.2.2.2.5.4.1-3
MEMNUL	8.2.2.2.5.4.1-2
MEMRX	8.2.2.2.5.4.1-2
MEMRXA	8.2.2.2.5.4.1-2
MEMRXB	8.2.2.2.5.4.1-3
MEMRXC	8.2.2.2.5.4.1-3
MEMSVI	8.2.2.2.5.4.1-2
MIFAST	8.2.2.2.1-4
MODEM8	8.2.3.6-1
MODEMA	8.2.3.6-2
MODEMB	8.2.3.6-1
MODEMC	8.2.3.6-1
MODEMC	8.2.3.6-3
MODEMD	8.2.3.6-2
MODEME	8.2.3.6-3
MODEMF	8.2.3.6-3
MODEMG	8.2.3.6-3
MODEMH	8.2.3.6-1
MODEMI	8.2.3.6-2



MOVWRD	8.2.3.4.2-6
MOVWRDA	8.2.3.4.2-6
MOVWRDB	8.2.3.4.2-6
NCH2	8.2.2.2-5
NCH2A	8.2.2.2-6
NCH3	8.2.2.2-6
NCHAR	8.2.2.2-5
NCHC	8.2.2.2-4
NEEDRP	8.2.3.5.2.1.2-1
NETCOM	8.2.2.2.2-3
NEWBUF	8.2.2.2-3
NEWBUFA	8.2.2.2-3
NEWBUFB	8.2.2.2-3
NEXTBF	8.2.3.5-4
NOPE	8.2.2.1.1-5
NOPROT	8.2.3.5.2.1-2
OI	8.2.2.2-1
OIBS	8.2.2.2.5.1-7
OIBSA	8.2.2.2.5.1-7
OIBSB	8.2.2.2.5.1-7
OIL1	8.2.2.2-6
OIL2	8.2.2.2-1
OILF	8.2.2.2.5.1-8
OITAB	8.2.2.2.5.1-9
OOPS	8.2.2-2
OUNEW	8.2.3.5.2.2.1-2
P01	8.2.2.2.5.1-4
P01A	8.2.2.2.5.1-6
P02	8.2.2.2.5.1-2
P03	8.2.2.2.5.1-5
P04	8.2.2.2.5.1-2
P05	8.2.2.2.5.1-5
P06	8.2.2.2.5.1-6
P09	8.2.2.2.5.1-3
P10	8.2.2.2.5.1-3
P11	8.2.2.2.5.1-4
P13	8.2.2.2.5.1-2
P14	8.2.2.2.5.1-5
P15	8.2.2.2.5.1-6
P15A	8.2.2.2.5.1-6
P15B	8.2.2.2.5.1-6
P17	8.2.2.2.5.1-5
PAR	8.2.2.1.3.1-6
PEND1	8.2.3.1-2
PEND3	8.2.3.1-2
PEND4	8.2.3.1-2
PEND5	8.2.3.1-2



PEND6	8.2.3.1-2
PEND7	8.2.3.1-3
PEND8	8.2.3.1-2
PENDA	8.2.3.1.1.1-1
PENDB	8.2.3.1.1.2-1
PENDB1	8.2.3.1.1.2-1
PENDB2	8.2.3.1.1.2-2
PENDC	8.2.3.1.2.1-1
PENDD	8.2.3.1.2.2-1
PENDE	8.2.3.1.1.3-1
PENDH	8.2.3.1.2.2-1
PENDIN	8.2.3.1-2
PENDUN	8.2.3.1.2.3-1
PRO3	8.2.3.2-3
PRO3A	8.2.3.2-3
PRO5	8.2.3.2-3
PRO5A	8.2.3.2-3
PROB1	8.2.3.2-2
PROB2	8.2.3.2-2
PROB3	8.2.3.2-2
PROBCK	8.2.3.2-2
PROT	8.2.3.5.2.1-2
PROTA	8.2.3.5.2.1-2
Q2	8.2.2.1.3.1-4
Q3	8.2.2.1.3.1-6
Q3A	8.2.2.1.3.1-6
Q6	8.2.2.1.3.1-7
Q8	8.2.2.1.3.1-8
Q9	8.2.2.1.3.1-8
QBA	8.2.2.1.3.1-7
REG	8.2.2.1.1-5
REGA	8.2.2.1.1-5
RESET	8.2.1-4
RESET5	8.2.1-4
RESETA	8.2.1-4
RESMOR	8.2.2.2.1-4
RETURN	8.2.2.1.3.1-5
RETURNA	8.2.2.1.3.1-5
RTS	8.2.3.5.2.1.1-3
SDIS	8.2.3.5-5
SEND6	8.2.3.4.1-1
SENDAB	8.2.3.4.1-1
SENDABA	8.2.3.4.1-2
SENDABB	8.2.3.4.1-1
SENDIT	8.2.3.4.2-2
SENDL1	8.2.3.4.2-4
SENDL1A	8.2.3.4.2-5



SENDL9	8.2.3.4.2-4
SENDOF	8.2.3.4.2-4
SENDW	8.2.3.4.2-3
SET6	8.2.2.2.4-2
SETOI	8.2.2.2.4-2
SETOI2	8.2.2.2.4-3
SETOIA	8.2.2.2.4-2
SETOIB	8.2.2.2.4-2
SETOIC	8.2.2.2.4-3
SFUDGE	8.2.2.2.2-1
SHUTDN	8.2.3.5.2.1.1-8
SLOWCR	8.2.2.2.5.2-1
SLOWCRA	8.2.2.2.5.2-2
SLOWCRB	8.2.2.2.5.2-1
SLOWCRC	8.2.2.2.5.2-1
SLOWCRD	8.2.2.2.5.2-2
SLOWCRE	8.2.2.2.5.2-2
SLURE	8.2.3.5-2
SLURP	8.2.3.5-2
SND RP	8.2.3.1.2.2-2
SND RPA	8.2.3.1.2.2-2
SPBYDM	8.2.2.2.2-1
SPBYTE	8.2.2.2.2-1
SPBYTEA	8.2.2.2.2-1
SPBYTEC	8.2.2.2.2-1
SPIAC	8.2.2.2.2-2
SPIACA	8.2.2.2.2-2
SSYN1	8.2.2.1.3.1-6
STR	8.2.3.5.2.1.1-3
SYNTAX	8.2.2.1.3.1-7
TE21	8.2.3.5.2.1.1-5
TE21A	8.2.3.5.2.1.1-5
TE31	8.2.3.5.2.1.1-5
TESTOK	8.2.3.5.2.1.1-5
TILEAD	8.2.3.4-1
TOHOST	8.2.3.4.2-8
TOOBAD	8.2.3.5.2.1.1-4
TOOBADA	8.2.3.5.2.1.1-4
TOOBADB	8.2.3.5.2.1.1-4
TOUT	8.2.4-2
TOUTA	8.2.4-2
UNBLK	8.2.3.5.1-7
UNBLKA	8.2.3.5.1-7
UNBLKB	8.2.3.5.1-7
UNBLKC	8.2.3.5.1-7
WILL	8.2.2.2.2-2



## ATTACHMENTS

- |      |                 |                  |
|------|-----------------|------------------|
| I.   | Macros          | MACROS,46,PARAMS |
| II.  | Concordance     | TIPCON,316,TIP   |
| III. | Listing         | TIPLST,316,TIP   |
| IV.  | Mag tape option | MAGLST,1,MAGTAP  |



